

Vigor 3300B+, 3300, 3300V

Installation Guide



DrayTek

Table of Contents

PART I	About this User Manual	ii
	Copyright.....	iii
	DrayTek Limited Warranty.....	iv
	Be a Registered Owner	iv
	Caution	iv
	Safety Instructions.....	v
	European Community Declarations.....	vi
	CE Declaration and Conformity.....	vii
	Customer Support.....	viii
	Organization.....	ix
PART II	Preface, Installation and Administration Setup.....	1-1
	CHAPTER 1. Preface and Installation.....	1-1
	CHAPTER 2. Administrator Password Setup	2-1
PART III	Quick Setup.....	3-1
	CHAPTER 3. Quick Setup	3-1
PART IV	Enhance Features.....	4-1
	CHAPTER 4. System Setup.....	4-1
	CHAPTER 5. Network Setup	5-1
	CHAPTER 6. Advance Setup	6-1
	CHAPTER 7. Firewall Setup.....	7-1
	CHAPTER 8. VPN and Remote Access Setup	8-1
	CHAPTER 9. VoIP Setup.....	9-1
	CHAPTER 10. Quality of Service Setup.....	10-1
PART V	Appendix A	A-1

About This User's Manual

This manual is designed to assist in using one of the Vigor 3300 series of multiservice Internet routers. The information contained in this document is subject to change without notice. If you have any inquiries, please feel free to contact our support team via E-mail, Fax or phone. For the latest product information and features, please visit our website at www.draytek.com.tw.

Copyright

Copyright © 2005 by DrayTek Corporation

All rights reserved. The information of this publication is protected by copyright. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language without written permission from the copyright holders.

Trademark

DrayTek is a registered trademark of DrayTek Corp. Vigor product series are trademarks of DrayTek Corp. Other trademarks and registered trademarks of products mentioned in this manual may be the properties of their respective owners and are only used for identification purposes.

Target Readers

This guide is intended for those responsible for hardware installation, and configuration for Vigor 3300 series.

DrayTek Limited Warranty

We warrant to the original end user (purchaser) that the routers will be free from any defects in workmanship or materials for a period of two (2) years from the date of purchase from the dealer. Please keep your purchase receipt in a safe place because it serves as the proof of purchase date.

During the warranty period, and upon proof of purchase, should the product have indications of failure due to faulty workmanship and/or materials, we will, at our discretion, repair or replace the defective products or components, without charge for either parts or labor, to whatever extent we deem necessary to restore the product to proper operating condition. Any replacement will consist of a new or remanufactured functionally equivalent product of equal value, and will be offered solely at our discretion. This warranty will not apply if the product is modified, misused, tampered with, damaged by an act of God, or subject to abnormal working conditions.

The warranty does not cover the bundled or licensed software of other vendors. Defects that do not significantly affect the usability of the product will not be covered by the warranty.

We reserve the right to revise the manual and online documentation and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Be a Registered Owner

Online web registration at www.draytek.com.tw is preferred. Alternatively, fill in the registration card and mail it to the address found on the reverse side of the card. Registered owners will receive future product and update information.

Caution

There is the risk of explosion if an incorrect type of battery is replaced.

Dispose of used batteries according to local environmental instructions.

Safety Instructions

■ **Operation Environment**

- Make sure that the AC power source is in the range of AC 90-240V.
The router should be used in a sheltered area, within a temperature range from 0 to +50 °C and relative humidity in the range of 10% and 90%.
- Do not expose the router to direct sunlight or other heat sources. The housing and electronic components may be damaged by direct sunlight or heat sources.

■ **Installation**

- Read the quick start guide and installation manual before turning on the power switch of device.
- Locate the emergency power-off switch near the device prior to power connection.
- Fixing the device on chassis to maintain air circulation and stable condition is recommended.
- Do not work alone if the operation environment is dangerous.
- Check and avoid the potential hazard for moist environment, and grounding issue for power cable.
- Please turn off the power switch when replace fuse, install or remove chassis.
- Do not place the device in a damp or humid place, e.g. a bathroom-like environment.
- Avoid operating cable connection during lightning period.
- When you want to dispose of the router, please follow local regulations on conservation of the environment.

■ **Maintenance**

- User can replace fuses by removing the module and replace it when necessary. Others components should be repaired by authorized and qualified personnel. Do not try to open or repair the device by yourself.
- The fuse should be identical to the following standard: 250VAC, 1A

European Community Declarations

DrayTek Corporation declares that the Vigor 3300 series of routers is in compliance with the essential requirements and other relevant provisions of R&TTE Directive 99/5/EC.

CE Declarations of Conformity



Declaration of Conformity

We DrayTek Corp. , office at No.26, Fu Shing Road, HuKou County, Hsin-Chu Industry Park, Hsinchu 300, Taiwan , R.O.C., declare under our sole responsibility that the product:

- Product name : MultiService Security Router
- Model number : Vigor 3300, Vigor 3300B, Vigor3300B+, Vigor 3300V

Produced by:

- Company Name: DrayTek Corp.
- Company Address: No.26, Fu Shing Road, HuKou County, Hsin-Chu Industry Park, Hsinchu 300, Taiwan , R.O.C.

to which this declaration relates is in conformity with the following standards or other normative documents:

Item	Description	Standard	Standard age
EMC	Conducted & Radiated Emission Standard	EN 55022 Class A	1998+A1:2000
	Current Harmonic	EN 61000-3-2 Class A	2000
	Voltage Fluctuation and Flicker	EN 61000-3-3	1995+A1:2001
	Immunity Standard	EN 55024	1998+A1:2001
	ElectroStatic Discharge	EN 61000-4-2	1995+A1;1998+A2:2000
	Radiated Susceptibility	EN 61000-4-3	1995+A1;1998+A2:2000
	Electrical Fast Transient/Buster	EN 61000-4-4	1995+A1;2001+A2:2001
	Surge	EN 61000-4-5	1995+A1:2000
	Conducted Susceptibility	EN 61000-4-6	1996+A1:2000
	Power Frequency Magnetic Field	EN 61000-4-8	1993+A1:2000
	Voltage Dips	EN 61000-4-11	1994+A1:2002
Safety	LVD Certificated	EN 60950-1	2001

Compliance with the directives of R&TTE 1999/5/EEC

DrayTek Corp.

Hsinchu
(place)

25 May, 2005
(date)

(Legal Signature)

Customer Support

Please prepare the following information before you contact your customer support.

- Product model and serial number,
- Warranty information,
- Date that you received Vigor 3300,
- Product configuration,
- Software release version number,
- Brief description of your problem,
- Steps that you may take to solve it and their associated SysLog messages.

The information of customer support and sales representatives are support@draytek.com.tw and sales@draytek.com.tw, respectively.

Organization

This document is separated into the following chapters:

Chapter	Title	Description	Page
1	Preface and Installation	Provides an overview product installation, LED indication and hardware installation.	1-1
2	Administrator Password Setup	Provides administrator password setup, update and verification.	2-1
3	Quick Setup	Provides a quick web setup instruction for basic feature of LAN and WAN.	3-1
4	System Setup	Provides a system setup for status, NTP, syslog, access control, reboot, firmware upgrade diagnostic tools and review.	4-1
5	Network Setup	Provides a setup instruction for LAN and WAN for load balance, HA and backup feature.	5-1
6	Advance Setup	Provides a setup instruction for static route, DMZ, Multi-port redirection, and LAN interface, and RADIUS.	6-1
7	Firewall Setup	Provides rule-based of how to configure firewall rule for packet filter, DOS, and URL.	7-1
8	VPN and Remote Access Setup	Provides the LAN to LAN and remote dial-in access for VPN connection setup.	8-1
9	VoIP Setup	Provides a setup for VoIP feature on FXS, FXO module. It covers SIP, MGCP, speed dial, codec setting, tone setting, QoS, NAT Traversal, incoming call barring.	9-1
10	Quality of Service Setup	Provide QoS setup mechanism.	10-1
Appendix A	PC Web Browser Setup	Provides setup of PC to configure Vigor 3300.	A-1

CHAPTER 1

Preface and Installation

1.1 Preface

The Vigor3300 product series integrates a rich suite of functions, including NAT, firewall, VPN, load balance, bandwidth management, and VoIP capability. These products are very suitable for providing multi-integrated solutions to SME markets. An application scenario for the Vigor3300 series is depicted in Figure 1-1, which illustrates interconnections among branch offices through the Internet via the Vigor3300 routers. By combining with an existing PABX, an Internet phone from a remote branch can also access any extension number on a local PABX or a traditional phone via PSTN. Also, by combining load balancing, data security, and Internet phone features, the company can benefit from reducing operation fees.




Figure 1-1. An application scenario of the Vigor3300 series

DrayTek

A Virtual Private Network (VPN) is an extension of a private network that encompasses links across shared or public networks like an Intranet. A VPN enables you to send data between two computers across a shared public Internet network in a manner that emulates the properties of a point-to-point private link. The DrayTek Vigor3300 series VPN router supports Internet-industry standards technology to provide customers with open, interoperable VPN solutions such as X.509, DHCP over Internet Protocol Security (IPSec) up to 200 tunnels, and Point-to-Point Tunneling Protocol (PPTP).

Internet Telephony, also known as Voice over Internet Protocol (VoIP), is a technology that allows you to make telephone calls using a broadband Internet connection instead of a regular (analog) phone line. Combining a PABX with a V3300V allows you to call anyone who has an Internet phone or a traditional telephone number – including local, long distance, mobile, and international numbers. Internet Telephony offers features and services that are unavailable with a traditional phone at no additional cost. Because Internet Telephony requires strictly minimal packet delay and jitter (since voice quality is intolerant of packet loss), the Vigor3300V integrates VoIP feature with QoS and packet loss concealment mechanisms to effectively transport high priority voice traffic over IP with low latency. Another feature is T.38 fax relay. By enabling and configuring fax rate on a dial peer, the originating and the terminating V3300V can enter fax relay transfer mode. By using the T.38 function, customers can also save on fax expenses. Lastly, by enabling the load balance feature on multiple WAN ports, lease lines can be replaced to provide a cost-effective method for network infrastructure.

The rest of this chapter is organized as following:

- Section 1.2: Connections and LED Indicators
- Section 1.3: Hardware Installation

1.2 Connections and LED Indicators

The Vigor3300 series has 4 WAN interfaces that support load balancing. This allows the system to reach peak performance and reduces the cost of maintaining a single high-speed trunk by sharing the load amongst the multiple WAN interfaces. Each interface can be connected to an individual Internet Service Provider. The Vigor3300 series also supports a backup function for WAN interfaces— a user can select one WAN interface to be a backup interface. If the master interface fails, the backup interface will take over as the master interface immediately. Lastly, the Vigor3300 series has a DMZ function can be applied to any LAN or WAN interface. Figure 1-2 illustrates the application of each interface in Vigor3300V.




Figure 1-2. Vigor3300 series network connection

The included auxiliary cables are listed in Table 1-1.

Table 1-1. The Vigor3300 connector specification


Auxiliary Cables	Type, Color	Connected to	Remarks
Power Cord	Black	AC Outlet	90-264VAC
Serial (Console)	RS232, Grey	PC RS232 port	--
Ethernet (LAN)	RJ-45, Blue	Ethernet switch or hub	--
Ethernet (DMZ)	RJ-45, Blue	Server	
Ethernet (WAN1)	RJ-45, Blue	DSL/Cable/Fiber Modem	--
Ethernet (WAN2)	RJ-45, Blue	DSL/Cable/Fiber Modem	
Ethernet (WAN3)	RJ-45, Blue	DSL/Cable/Fiber Modem	
Ethernet (WAN4)	RJ-45, Blue	DSL/Cable/Fiber Modem	

To connect the router to your system:


- 1. Connect the power cord in the rear panel of the Vigor3300 to an AC outlet. The PWR LED should light up.
- 2. After system testing is completed, the ACT LED will begin to blink.
- 3. Connect your local network to any of the 4 LAN ports on the Vigor3300 with a blue RJ-45 cable, and the LAN LED will blink.

The Vigor3300 provides LEDs for VPN, Firewall, QoS, VoIP, and the 4 WAN ports. All of these LEDs are depicted in Figure 1-3 and the function of each LED is described in Table 1-2.

(Vigor 3300 Front Panel LED)



(VoIP Module-FXS)



(VoIP Module-FXO)




Figure 1-3. LED indicators of the Vigor3300

Table 1-2. The Vigor3300V front panel LED and its description

LED Indication		Color	Description	Remarks
PWR		Green	Power ON	
		OFF	Power OFF	
ACT		Green/Blinking	Blinks when system is active	
		OFF	When System is hanging	
WAN, Px	LNK	Green/Blinking	Green when Ethernet link is established; Blinks during data transit	Px: Port x, where x is
		OFF	No Ethernet link established	
	100M	Green	The speed for Ethernet is 100Mbps	
		OFF	The speed for Ethernet is 10Mbps	
	FDX	Green	The Ethernet is in full duplex mode	
		OFF	The Ethernet is in half duplex mode	
LAN, Px	LNK	Green	Ethernet link is established on port Px	Px: Port x, where x is
		OFF	No Ethernet established on port Px	
	100M	Green	The speed for Ethernet is 100Mbps on port Px	
		OFF	The speed for Ethernet is 10Mbps on port Px	
	FDX	Green	The Ethernet is in full duplex mode on port Px	
		OFF	The Ethernet is in half duplex mode on port Px	
DMZ		As WAN	As WAN ports	As WAN ports
VPN		Green	VPN is active	Not in V3300B and V3300B+
		OFF	VPN is not active	
Firewall		Green	Firewall is active	
		OFF	Firewall is not active	
QoS		Green	QoS is active	
		OFF	QoS is not active	
FXO, Px		Green	VoIP call is in use for corresponding port	Px Port for FXO module, x is 1-4
FXS , Px		Green	VoIP call is in use for corresponding port	Px Port for FXS module, x is 1-4

1.3 Hardware Installation

Figure 1-4 shows the interface of the Vigor3300 series. The Vigor3300V supports console, 4 LAN switch ports, 4 WAN interfaces, and two 4-port extensible VoIP channels. The Vigor3300 series also provides different color-type cables for each individual interface. The interface and color types are listed on Table 1-3. Figure 1-4 illustrates the front panel connectors of the Vigor3300 series.




Figure 1-4. Hardware interface on front panel

Table 1-3. Connector types and color types

Connector Type	Color	Description	Remarks
Console	Gray	RJ45 and DB9 cable to PC	For craft command control
LAN	Blue	RJ45 to RJ45 cable to WAN	For LAN network connection
WAN	Blue	RJ45 to RJ45 cable to LAN	For WAN network connection
Phone		RJ11 to PABX cable or RJ11 to Phone cable	Requires an RJ11 phone cable (not included)

1.3.1 Descriptions of Connectors and Interfaces

1.3.1.1 The RS232 Connector

The RJ45 connection jet is used for CLI commands for system configuration and control functions in the Vigor3300. The jet is used for initialization of the Vigor3300 during preliminary installation. The “management cable”, as shown in Figure 1-5, converts the RJ45 to the RS232 interface. The RJ45 jet connects to a console interface in the Vigor3300, while the RS232 DB9 connects to a console port on the computer. The default setting of the console port is “**baud rate 57600, no parity, and 8 bit with 1 stop bit.**”




Figure 1-5. Console management cable



The pin-out for this connector is shown in Table 1-4 as follows:

Table 1-4. The RS232 connector pinout

RJ45	DB9	Signal
X	1	CD
3	2	TD
6	3	RD
7	4	DTR
5	5	GND
2	6	DSR
8	7	RTS
1	8	CTS
X	9	RI

1.3.1.2 Standard 10/100 Base-T Ethernet Interface Connector

RJ45 jacks provide 10/100 Base-T Ethernet interfaces. The interface supports MDI/MDIX auto-detection of either straight or crossover RJ45 cables. These cables are used on WAN, LAN, and DMZ interfaces.



RJ-45 Straight-through Cable Pin-outs			
Signal	Pin	Pin	Signal
Tx+	1	1	Tx+
Tx-	2	2	Tx-
Rx+	3	3	Rx+
--	4	4	--
--	5	5	--
Rx-	6	6	Rx-
-	7	7	-
-	8	8	-

RJ-45 Crossover Cable Pin-outs			
Signal	Pin	Pin	Signal
Tx+	1	1	Tx+
Tx-	2	2	Tx-
Rx+	3	3	Rx+
--	4	4	--
--	5	5	--
Rx-	6	6	Rx-
-	7	7	-
-	8	8	-

1.3.2 Chassis Connections

1.3.2.1 Rack-Mounting the Chassis

The Vigor3300 series can be mounted on a rack by using standard brackets in a 19-inch rack or optional larger brackets on 23-inch rack (not included). The bracket for 19- and 23-inch racks are shown in Figure 1-7.




Figure 1-7. Bracket for 19-, 23-inch rack

Attach the brackets to the chassis of a 19- or a 23-inch rack (as shown in the Figures 1-8 and 1-9). Repeat the above procedure for the second bracket, which attaches the other side of the chassis.




Figure 1-8. Bracket installation for front mounting on a 19- and a 23-inch rack




Figure 1-9. Bracket installation for front mounting on a 19- or a 23-inch rack

After the bracket installation, the Vigor3300 chassis can be installed in a rack by using four screws for each side of the rack.

1.3.2.2 Desktop Type Installation

Rubber pads are included with the Vigor3300. These rubber pads improve the air circulation and decrease unnecessary rubbing on the desktop.

1.3.2.3 Power, Ground Connections on the Rear Panel

The AC input and ground connections are on the rear panel and shown on Figure 1-10. You can connect the rack to the ground with screws.




Figure 1-10. The rear panel and AC power input

DrayTek

CHAPTER 2

Administrator Password Setup

This chapter explains how to setup a password for an administrator. This allows only the administrator to change the router configuration.

This chapter is divided into the following sections.

- Section 2.1: Introduction
- Section 2.2: Changing the Administrator Password

2.1 Introduction

In the **System** group, click the **Change Password** option. The user can then setup a password for the administrator. Figure 2-1 illustrates the location of the Change Password option.




Figure 2-1.Option of change password

Administrator Password Setup

Click the **Change Password** option to bring up the following page. Figure 2-2 illustrates the Web page as an example.

The screenshot shows the Vigor3300 series MultiService Security web interface. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The System - Administrator page is displayed, featuring three input fields for Old Password, New Password, and Confirm Password. The time shown is 11:09:40 A.M. The footer contains the text: DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 2-2. Administrator of system group

2.2 Changing the Administrator Password

It is recommended that you set a password for the router for security. The default user name for the Vigor3300 series is “**draytek**” and password is “**1234**”. Figure 2-3 illustrates the Web page after changing the settings.

The screenshot shows the same Vigor3300 series MultiService Security web interface as Figure 2-2, but with the password fields masked with dots. The time shown is 11:13:15 A.M. The footer contains the text: DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 2-3. Administrator password settings

Administrator Password Setup

Old Password	Assign the current administrator password. If this is your first time setting a password, please type the default password “1234”.
New Password	Assign a new administrator’s password.
Confirm Password	Retype the new password for confirmation.

Please click **Apply** to apply these settings into the Vigor3300 device.

You will see the login screen after clicking **Apply**. You should use the new password to re-enter the system configuration. Figure 2-4 illustrates the login screen after clicking **Apply**.



Figure 2-4. Login screen

CHAPTER 3

Quick Setup

This chapter explains more details about the Quick Setup. The Quick Setup provides an easy way to configure the Vigor3300.

This chapter is divided into the following sections.

- Section 3.1: WAN Setting
- Section 3.2: LAN Interface Configuration

If your Vigor3300 is used under a high speed NAT environment, these settings can help you to install and deploy quickly.

3.1 WAN Setting

In the **Quick Setup** group, you can configure the router to access the Internet with different modes such as Static, DHCP, PPPoE, or PPTP modes. For most users, Internet access is the primary application. The router supports the Ethernet WAN interface for Internet access. The following sections will explain in more detail the various broadband access configurations. All settings in this section will be applied in the first WAN1 interface. Figure 3-1 illustrates the web page as an example.

Quick Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick SetupSystemNetworkAdvancedFirewallQoSVPNVoIP11:44:43 A.M.

Quick Setup - WAN

MAC Address :
☒ Default MAC ☐ User Defined MAC

Downstream Rate :
 (kbps)

Upstream Rate :
 (kbps)

Type :

Physical Mode :

IP Mode :
☒ Static ☐ DHCP ☐ PPPoE ☐ PPTP

Static/DHCP Configuration

PPPoE/PPTP Configuration

IP Address :

Subnet Mask :

Default Gateway :

Primary DNS :

Secondary DNS :

Host Name :

Domain Name :

(Host Name and Domain Name are required for some ISPs.)

IP Alias List

1.

2.

3.

4.

5.

6.

7.

8.

Next >>

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-1. The quick setup

Quick Setup

MAC Address	
Router Default	Use the default Mac address stored originally in router.
User Definition	Use a MAC address defined by the user.

Downstream Rate	Assign the downstream rate for this WAN interface. The default value is 102400 kbps (100 Megabit). The setting is very important for Vigor3300 incoming buffer adjustment. If you use a DSL subscriber service with a 2Mbps downstream, set the downstream rate setting is 2Mbps.
Upstream Rate	Assign the transmission rate for this WAN interface. The default value is 102400 kbps (100 Megabit). The setting is very important for Vigor3300 incoming buffer adjustment. If you use a DSL subscriber service with a 256Kbps downstream, set the downstream rate setting is 256Kbps.
Type	Select a connection type for this WAN interface.
Physical Mode	Select connection speed mode for this WAN interface. There are auto negotiation , full duplex , and half duplex of either 10M or 100M speed options for the WAN Interface.
IP Mode	Select an IP mode for this WAN interface. There are four available modes for Internet access, Static , DHCP , PPPoE , and PPTP . On this page you may configure the WAN interface to use Static (fixed IP), DHCP (dynamic IP address), PPPoE or PPTP . Most of the cable users will use the DHCP mode to get a globally reachable IP address from the cable host system.

3.1.1 Static Setup

You can manually assign a static IP address to the WAN interface and complete the configuration by applying the settings and rebooting your router. Then you will see the following web page. Figure 3-2 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 11:53:12 A.M.

Quick Setup - WAN

MAC Address : ☒ Default MAC ☐ User Defined MAC

Downstream Rate : (kbps)

Upstream Rate : (kbps)

Type :

Physical Mode :

IP Mode : ☒ Static ☐ DHCP ☐ PPPoE ☐ PPTP

Static/DHCP Configuration PPPoE/PPTP Configuration

IP Address : Host Name :

Subnet Mask : Domain Name :

Default Gateway : (Host Name and Domain Name are required for some ISPs.)

Primary DNS :

Secondary DNS :

IP Alias List

1.	<input type="text" value="10.1.1.100"/>	2.	<input type="text" value="10.1.1.104"/>
3.	<input type="text" value="10.1.1.101"/>	4.	<input type="text" value="10.1.1.105"/>
5.	<input type="text" value="10.1.1.102"/>	6.	<input type="text" value="10.1.1.106"/>
7.	<input type="text" value="10.1.1.103"/>	8.	<input type="text" value="10.1.1.107"/>

Next >>

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-2. Static configuration

Quick Setup

<i>IP Address</i>	Assign a private IP address to the WAN interface.
<i>Subnet Mask</i>	Assign a subnet mask value to the WAN interface.
<i>Default Gateway</i>	Assign a private IP address to the gateway.
<i>Primary DNS</i>	Assign a private IP address to the primary DNS.
<i>Secondary DNS</i>	Assign a private IP address to the secondary DNS.
<i>IP Alias List</i>	Assign other IP addresses to be bound to this interface.

After setting up the **WAN** interface, the user can click **Next>>** to setup the **LAN** interface.

3.1.2 DHCP Client Setup

DHCP allows a user to obtain an IP address automatically from a DHCP server on the Internet. If the **WAN** interface is set as a DHCP client, it will ask for a specific IP address and network settings from a DHCP server or DSL modem. If a user selects this mode, it is not necessary for the user to setup any configuration. (Host Name and Domain Name are required for some ISPs). Figure 3-3 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 12:04:09 A.M.

Quick Setup - WAN

MAC Address : ☒ Default MAC ☐ User Defined MAC

Downstream Rate : (kbps)

Upstream Rate : (kbps)

Type :

Physical Mode :

IP Mode : ☐ Static ☒ DHCP ☐ PPPoE ☐ PPTP

Static/DHCP Configuration PPPoE/PPTP Configuration

IP Address : Host Name :

Subnet Mask : Domain Name :

Default Gateway : (Host Name and Domain Name are required for some ISPs.)

Primary DNS :

Secondary DNS :

IP Alias List

1.	<input type="text" value="10.1.1.100"/>	2.	<input type="text" value="10.1.1.104"/>
3.	<input type="text" value="10.1.1.101"/>	4.	<input type="text" value="10.1.1.105"/>
5.	<input type="text" value="10.1.1.102"/>	6.	<input type="text" value="10.1.1.106"/>
7.	<input type="text" value="10.1.1.103"/>	8.	<input type="text" value="10.1.1.107"/>

Next >>

DrayTek Corp. © 1997 ~ 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-3. The DHCP configuration

After setting up the **WAN** interface, the user can click **Next>>** to setup the **LAN** interface.

3.1.3 PPPoE with a DSL Modem

This mode is used for most of DSL modem users. All local users can share one PPPoE connection to access the Internet. The following setup web page is just as an example. Your service provider should provide the user name, password, and authentication mode for PPPoE settings. Figure 3-4 illustrates the web page after clicking the **PPPoE** option.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 1:19:57 P.M.

Quick Setup - WAN

MAC Address : ☒ Default MAC ☐ User Defined MAC
00:50:7f:2f:c4:c6

Downstream Rate : (kbps)

Upstream Rate : (kbps)

Type :

Physical Mode :

IP Mode : ☐ Static ☐ DHCP ☒ PPPoE ☐ PPTP

Static/DHCP Configuration **PPPoE/PPTP Configuration**

User Name :

Password :

Authentication :

Service Name :

PPTP Local Address :

PPTP Subnet Mask :

PPTP Remote Address :

Next >>

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-4. The PPPoE configuration

User Name	Assign a specific valid user name provided by the ISP.
Password	Assign a valid password provided by the ISP.
Authentication	Select PAP or CHAP protocol for PPP authentication. The default value is PAP .
Service Name	Assign a service name required from ISP service.

Quick Setup

After setting up the WAN interface, the user can click **Next>>** to setup the LAN interface.

3.1.4 PPTP with a DSL Modem setup

This mode is to let user get the IP group information by a DSL modem with PPTP service from an ISP. The following setup web page is used as an example. Your service provider should provide the user name, password, and authentication mode for a PPTP setting. Figure 3-5 illustrates the example web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 4:03:00 P.M.

Quick Setup - WAN

MAC Address : ☒ Default MAC ☐ User Defined MAC
00:50:7f:c4:c6

Downstream Rate : (kbps)

Upstream Rate : (kbps)

Type :

Physical Mode :

IP Mode : ☐ Static ☐ DHCP ☐ PPPoE ☒ PPTP

Static/DHCP Configuration **PPPoE/PPTP Configuration**

User Name :

Password :

Authentication :

Service Name :

PPTP Local Address :

PPTP Subnet Mask :

PPTP Remote Address :

Next >>

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-5. The PPTP configuration

PPTP Local Address	Assign a local IP address of PPTP.
PPTP Subnet Mask	Assign a net mask value for IP address of PPTP.
PPTP Remote Address	Assign a remote IP address of PPTP server.

After setting up the **WAN** interface, the user can click **Next>>** to setup the **LAN** interface.

3.2 The LAN Interface Configuration

The LAN interface on the Vigor3300 series has one IP address. There are three options available to the user:

- *IP Configuration**

- *1st DHCP Server**

- *2nd DHCP Server**

3.2.1 IP Configuration

There are some IP address settings for the LAN interface as described below. The IP address/subnet mask is for private users or NAT users. In general, the LAN IP address is 192.168.1.X. Other local PCs should set the default gateway to be the LAN IP address of the Vigor3300. When the connection to the ISP is established, each local PC will directly route to the Internet. Also, you could use the IP address/subnet mask to connect to other private PCs users. On the following web page, you will see the private IP address defined in RFC-1918. Usually, we use the 192.168.1.0/24 subnet for the router. To allow public users, you need to have subscribed to a globally reachable subnet from your ISP. After clicking the IP Configuration option, you will see the following web page. Figure 3-6 illustrates the web page as an example.

Quick Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 11:27:30 A.M.

Network - LAN

IP Configuration 1st DHCP Server 2nd DHCP Server

For NAT Usage

1st IP Address : 192.168.1.1

1st Subnet Mask : 255.255.255.0

For IP Routing Usage

☐ Enable ☒ Disable

2nd IP Address :

2nd Subnet Mask :

WAN Interface : WAN1

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-6. The LAN interface configuration

NAT Usage	
1st IP Address	The first private IP address for connecting to a local private network. The default value is 192.168.1.1.
1st Subnet Mask	The first subnet mask of the local private network. The default value is 255.255.255.0.
IP Routing Usage	
Status	Click “ Enable ” to enable this function. Click “ Disable ” to disable this function.
2nd IP Address	Assign an IP address belongs to the subnet of the WAN selected in WAN Interface field.
2nd Subnet Mask	Assign the value of subnet mask.
WAN Interface	Select a WAN interface to be applied in IP Routing Usage.

Click the **Finish** option, and the user will be prompted to reboot. Reboot the system to save your settings.

3.2.2 DHCP Server Configuration

DHCP stands for Dynamic Host Configuration Protocol. It can automatically dispatch related IP settings to any local user configured as a DHCP client. Please refer to the following figure for DHCP server configuration.

3.2.2.1 The 1st DHCP Server Setting

After clicking the 1st DHCP Server option, you will see the following web page. Figure 3-7 illustrates the web page as an example.

The screenshot displays the 'Quick Setup - LAN' configuration page for the '1st DHCP Server'. The interface includes a top navigation bar with tabs for 'Quick Setup', 'System', 'Network', 'Advanced', 'Firewall', 'QoS', 'VPN', and 'VoIP'. The 'Quick Setup' tab is active, and the '1st DHCP Server' sub-tab is selected. The configuration fields are as follows:

- Status:** Radio buttons for 'Enable' (selected), 'Disable', and 'Relay Agent'.
- Start IP:** Text box containing '192.168.1.10'.
- End IP:** Text box containing '192.168.1.254'.
- Primary DNS:** Text box containing '168.95.1.1'.
- Secondary DNS:** Text box containing '168.95.192.1'.
- Lease Time (Min):** Text box containing '1400'.
- Gateway IP(Optional):** Empty text box.
- Relay Agent:** Section header.
- WAN Interface:** Dropdown menu showing 'WAN1'.
- DHCP Server IP Address:** Empty text box.

At the bottom right, there are two buttons: '<<Previous' and 'Finish'. The footer of the page contains the text: 'DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 3-7. The 1st DHCP server configuration

Quick Setup

Status	Click “ Enable ” to enable this function. Click “ Disable ” to disable this function. Click “ Relay Agent ” to apply this function.
Start IP	Set the starting IP address of the IP address pool.
End IP	Set the ending IP address of the IP address pool.
Primary DNS	Assign the IP address of the primary DNS.
Secondary DNS	Assign the IP address of the secondary DNS.
Lease Time (Min)	Assign the lease time of DHCP server to client.
Gateway IP(Optional)	Assign a new gateway IP address to DHCP client.
Relay Agent	
WAN Interface	Select a WAN interface which the other DHCP server is from.
DHCP Server IP Address	Assign an IP address of the other DHCP server.

Click the **Finish** option, and the user will be prompted to reboot. Reboot the system to save your settings.

3.2.2.2 The 2nd DHCP Server Setting

The Vigor3300 series routers support a second DHCP server. Click the 2nd DHCP Server option to bring up the following web page. Figure 3-8 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 3:12:25 P.M.

Quick Setup - LAN

IP Configuration 1st DHCP Server **2nd DHCP Server**

Start IP Address : 192.168.2.10

IP Pool Size : 10

MAC Address List (MAC Address Format xx:xx:xx:xx:xx:xx)

1.	00:00:0a:00:00:01	2.	00:00:0a:00:00:02
3.	00:00:0a:00:00:03	4.	00:00:0a:00:00:04
5.	00:00:0a:00:00:05	6.	00:00:0a:00:00:06
7.	00:00:0a:00:00:07	8.	00:00:0a:00:00:08
9.	00:00:0a:00:00:09	10.	00:00:0a:00:00:0a

<<Previous Finish

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 3-8. The 2nd DHCP server configuration

Start IP Address	Set the starting IP address of the IP address pool.
IP Pool Size	Assign the number how many IP addresses in the pool.
Mac Address List	Assign up to 10 MAC addresses to be served. Once a MAC address is matched in this table, the corresponding IP address and associated information will be returned.

Quick Setup

Click the **Finish** option, and the user will be prompted to reboot. Reboot the system to save your settings. Figure 3-9 illustrates the web page after clicking **Finish**.




Figure 3-9. System reboot

Click the **Apply** option to reboot the Vigor3300 with the new configurations.

CHAPTER 4

System Setup

This chapter shows how to configure the System.

This chapter is divided into the following sections.

- Section 4.1: Status.
- Section 4.2: Time Setup
- Section 4.3: Syslog Setup
- Section 4.4: Access Control Setup
- Section 4.5: Reboot and Firmware Upgrade Setup
- Section 4.6: Diagnostic Tools
- Section 4.7: Configuration Setup

4.1 Status

The online **Status** function provides some useful system information on the current status of the Vigor3300 series. A user can also observe the system status on this Web page. In the **System** group, click the **Status** option. The online **Status** Web page contains three parts: **Basic Status**, **LAN Status**, and **WAN Status**. Figure 4-1 shows the location of the **Status** option.

System Setup




Figure 4-1. Status option

Figure 4-2 illustrates the status Web page as an example.




Figure 4-2. The system status

Refresh Option	<p>You can choose to automatically refresh the Web page information.</p> <p>There are four options given as shown below.</p> <ul style="list-style-type: none">● No Refresh: Static information page.● Every 10 Seconds: Refresh page every 10 seconds.● Every 20 Seconds: Refresh page every 20 seconds.● Every 30 Seconds: Refresh page every 30 seconds.
-----------------------	--

4.1.1 Basic Status

Click the **Basic Status** option to see the following Web page as shown in Figure 4-3.

The screenshot displays the web interface for the Vigor3300 series MultiService Security device. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The main content area is titled 'System - Status' and features a 'Refresh Option' dropdown menu set to 'Every 10 Seconds'. Below this, there are three tabs: 'Basic Status' (selected), 'LAN Status', and 'WAN Status'. The 'Basic Status' tab shows the following information:

Model :	Vigor3300V
Hardware Version :	1.0
Firmware Version :	2.5.6 RC3
Build Date&Time :	Tue Sep 13 17:42:00 CST 2005
System Uptime :	0 days 0 hours 5 minutes 45 seconds
CPU Usage :	9.2593%
Memory Usage :	59.2540%
Current System Time :	Fri Sep 23 00:17:47 2005

At the bottom of the page, a copyright notice reads: 'DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 4-3. The basic status

System Setup

Model	The model name of the router.
Hardware Version	The hardware version of the router.
Firmware Version	The firmware version of the router.
Build Date&Time	The date and time of the current firmware build.
System Uptime	The amount of time that the router has been online.
CPU Usage	The average percentage of the CPU being used.
Memory Usage	The percentage of memory being used.
Current System Time	The current local system time.

4.1.2 LAN Status

Click the **LAN Status** option to bring up the following Web page as shown in Figure 4-4.




Figure 4-4. The LAN status

System Setup

<i>IP Address</i>	IP address of the LAN interface.
<i>MAC Address</i>	MAC address of the LAN Interface.
<i>High Available Status</i>	<p>The High Available Status is shown when the function is enabled. There are two options shown as follows.</p> <ul style="list-style-type: none">● Master: Vigor3300 plays the Master role in high availability feature.● Slave: Vigor3300 plays the Slave role in high availability feature.
<i>RX Packets</i>	Number of total number of received packets at the LAN interface.
<i>TX Packets</i>	Number of total transmitted packets at the LAN interface.

4.1.3 WAN Status

Click the **WAN Status** option to bring up the following Web page as shown in Figure 4-5. There is some basic information displayed for all the four WAN interfaces.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 4:24:13 P.M.

System - Status

Refresh Option: Every 10 Seconds

Basic Status	LAN Status	WAN Status
WAN1 :		
IP Address :	172.16.2.225	
MAC Address :	00:50:7f:2f:c4:c6	
Primary DNS :	168.95.1.1	
Secondary DNS :	168.95.192.1	
Gateway :	172.16.2.233	
RX Packets :	13088	
TX Packets :	2165	
Connection Status :	connected	
Up Time :	0 days 0 hours 11 minutes 44 seconds	
WAN2 :		
IP Address :		
MAC Address :	00:50:7f:2f:c4:c7	
Primary DNS :		
Secondary DNS :		
Gateway :		
RX Packets :		
TX Packets :		
Connection Status :		
Up Time :		
WAN3 :		
IP Address :		
MAC Address :	00:50:7f:2f:c4:c8	
Primary DNS :		
Secondary DNS :		
Gateway :		
RX Packets :		
TX Packets :		
Connection Status :		
Up Time :		
WAN4 :		
IP Address :		
MAC Address :	00:50:7f:2f:c4:c9	
Primary DNS :		
Secondary DNS :		
Gateway :		
RX Packets :		
TX Packets :		
Connection Status :		
Up Time :		

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 4-5. The WAN status

System Setup

<i>IP Address</i>	The IP address of the WAN interface.
<i>MAC Address</i>	The MAC address of the WAN Interface.
<i>Primary DNS</i>	The assigned IP address of the primary DNS.
<i>Secondary DNS</i>	The assigned IP address of the secondary DNS.
<i>Gateway</i>	The assigned IP address of the default gateway.
<i>RX Packets</i>	The number of total received packets for each WAN interface.
<i>TX Packets</i>	The number of total transmitted packets for each WAN interface.
<i>Connection Status</i>	Display the detecting status of the WAN interface <i>Connected:</i> The WAN port is working.
<i>Up Time</i>	The total system uptime of the interface.

4.2 Time Setup

As an NTP (Network Time Protocol) client, the router gets standard time from the time server. Some time-based functions, which are Call Schedule and URL Content filtering, cannot work properly until system time functions run successfully. Typically, NTP achieves high accuracy and reliability with multiple redundant servers and diverse network paths.

The Vigor3300 series supports synchronization with a specific NTP server or the remote PC host of the administrator. In the **System** group, click the **Time** option. Figure 4-6 illustrates the location of the **Time** option.




Figure 4-6. The Time option under the system group

System Setup

After clicking **Time** option, you will see the following Web page as shown in Figure 4-7.

Figure 4-7. The Time configuration

Use Browser Time	Click this option to use the browser time from the remote administrator PC host as 3300 system time.
Use NTP Time	Click this option to use the time from an NTP server as 3300 system time.
NTP Server	Assign a public IP address or domain name of the NTP server.
Time Zone	Select the time zone where the Vigor3300 is located.
Daylight Savings Time	Select “Use” to activate this function.
Update Interval	Select a time interval for updating from the NTP server.

Click **Apply** to save these settings.

4.3 Syslog Setup

The Vigor3300 series supports a Syslog function to keep a record of abnormal conditions. The router will send Syslog packets to a Syslog server on the remote site. The administrator can observe any abnormal events on the Vigor3300.

In the **System** group, the click **Syslog** option. Figure 4-8 illustrates shows the location of this option.




Figure 4-8. The Syslog option

After clicking the **Syslog** option, you will see the following Web page as shown in Figure 4-9.

Figure 4-9. The Syslog configuration

Status	Click “ Enable ” to activate this function.
Syslog Server IP	The IP address of the Syslog server. If the user assigns an IP address of “0.0.0.0”, the Syslog function will be disabled. Vigor3300 will not send Syslog packets to the Syslog server.
Syslog Server Port	Assign a port for the Syslog protocol.

Click **Apply** to save these settings.

4.4 Access Control Setup

Access control protects the user from ICMP attacking from virus-launched routers. You can disable the ping function from the LAN side when there are worm-type viruses on your LAN network to prevent the virus from spreading. However, such a configuration is not suggested under normal circumstances because it will also block normal query packets.

System Setup

In the **System** group, click the **Access Control** option to bring up the following Web page as shown in Figure 4-10.




Figure 4-10. The access control option

System Setup

After clicking the **Access Control** option, you will see the following setup Web page as shown in Figure 4-11.

The screenshot displays the web interface for the Vigor3300 series MultiService Security device. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The current page is titled "System - Access Control".

Management Access Control

Allow Management from the WAN

☐ Disable ☒ Enable All ☐ Enable User Defined WAN IP

Allowed IP1:
Allowed IP2:
Allowed IP3:

Management Port

☒ Default Ports (HTTP Port:80 Telnet Port:23) ☐ User Defined Ports

HTTP Port:
Telnet Port:

PING Restriction

☐ Disable PING from the LAN
☐ Disable PING from the WAN

At the bottom right, there are "Apply" and "Cancel" buttons. The footer contains the text: "DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution."

Figure 4-11. The access control configuration

The **Management Port** function allows the user to set a port number or to use the default port number in the Vigor3300 series. An administrator can allow three dedicated IP addresses to manage the system via WAN.

Management Access From WAN	
Disable All	Disable all management functions from the WAN interface.
Enable All	Enable all management functions from the WAN interface.
Enable User Defined WAN IP	System can be managed by these three IP addresses via WAN.
Management Port	
Default Ports (Http Port:80 Telnet Port:23)	Use the default ports for HTTP and Telnet
User Defined Ports	User can assign the new port numbers for HTTP and Telnet.
PING Restriction	
Disable PING from the LAN	Choose this function to reject all ICMP packets from LAN side.
Disable PING from the WAN	Choose this function to reject all ICMP packets from WAN side.

Click **Apply** to save these settings.

4.5 Reboot and Firmware Upgrade Setup

4.5.1 Reboot Setup

The Vigor3300 system can be restarted from a Web browser. In the **System** group, click the **Reboot** option. Figure 4-12 illustrates the location of the Reboot option.




Figure 4-12. The reboot option

After clicking the **Reboot** option, you will see the following Web page as shown in Figure 4-13. The user should choose to either keep the current configuration settings or use the default configuration after the Vigor3300 system has been rebooted.




Figure 4-13. The reboot configuration

Click **Apply** to reboot the whole system. The rebooting procedure usually takes 70 or more seconds. Figure 4-14 illustrates the reboot screen.



Figure 4-14. Reboot countdown

4.5.2 Firmware Upgrade by TFTP Server

Before upgrading your router firmware, you need to install the router tools on your local PC, which contains the Firmware Upgrade Utility. The following outlines the methods for upgrading the firmware on your router.

4.5.2.1 Firmware Upgrade from Web

Vigor3300 supports the function to upgrade firmware through a Web interface. In the **System** group, click the **Firmware Upgrade** option to bring up the following Web page as shown in Figure 4-15.

System Setup




Figure 4-15. The firmware upgrade option

After clicking the **Firmware Upgrade**, you will see the following Web page.

Figure 4-16 illustrates an example of this Web page running on a Windows environment.

System Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 12:10:53 A.M.

System - Firmware Upgrade

Caution : You need to reboot device no matter upgrade succeeded or not !!

Current Version : Vigor3300V 2.5.6 RC3

Location : ☒ Local ☐ Remote

Firmware : D:\Program Files\V3K32256_en_P

TFTP Server IP

Remote File Name

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 4-16. The firmware upgrade configuration

Location	Local: Upgrade firmware from a local TFTP server. Remote: Upgrade firmware from a remote TFTP server.
Firmware	If upgrading locally, select the location of the firmware file.
TFTP Server IP	If upgrading remotely, enter the IP address of the TFTP server.

To upload new firmware to your router:

1. Download the newest firmware from the DrayTek's Website (www.draytek.com.tw) or FTP site ([ftp.draytek.com](ftp://ftp.draytek.com)).
2. Click the **Browse** button to locate the new firmware file and click **Apply**. The firmware will be prepared for upgrading and the status will be shown on the progress bar.
3. Click **Apply** to start the upgrading procedure. This process takes 3-5 minutes, and the router will reboot automatically once the upgrade is complete.

4.5.2.2 Firmware Upgrade from a Console Port

This section outlines how to perform a firmware upgrade from a console port. The following example was run on a Windows environment.

1. Download the newest firmware from the DrayTek Website (www.draytek.com.tw) or FTP site ([ftp.draytek.com](ftp://ftp.draytek.com)).
2. Use the console management cable to connect the RJ45 connector to a console port on the Vigor3300 and the DB9 connector to an RS232 port on the PC. The default setting of the console port is “baud rate 57600, no parity, and 8 bit with 1 stop bit.” Figure 4-17 illustrates an example of the console setup on a PC.




Figure 4-17. The console setup

3. Power on the Vigor3300, then press **ENTER** on the PC before the system reboots completely. The Vigor3300 can now accept a TFTP download and will display the following message:

*** DrayTek V3300 Bootloader ***

Press [ENTER] key within 5 sec. to download image...2

Current LAN IP is 192.168.1.1

New IP:

Prepare downloading.

4. Type the path name of the firmware image and start the **TFTP Client** from the PC to download the image. The corresponding message is shown as follows.

TFTP -i 192.168.1.1 PUT [Vigor3300 image file name]

5. After upgrading is finished, the system will automatically reboot.

4.6 Diagnostic Tools

In some cases, a user may need to know some information the router, such as some static or dynamic databases, or other routing information. The Vigor3300 series supports four functions for the user to review this information.

The Vigor3300 series diagnostic tool has four functions:

- * Routing Table
- * ARP Cache Table
- * DHCP Assignment Table
- * NAT Active Sessions Table

We will give more detailed descriptions in following sections.

In the **System** group, click the **Diagnostic Tools** option, and then you will see the following Web page as shown in Figure 4-18.




Figure 4-18. Functions of the diagnostic tools

4.6.1 The View Routing Table

After clicking the **View Routing Table** option, you will see the following Web page as shown in Figure 4-19.

Vigor3300 series .
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 5:48:44 P.M.

System - Diagnostic Tools - View Routing Table

Destination	Gateway	Subnet Mask	Flags	Interface
172.16.2.0	*	255.255.255.0	U	eth0
1.1.1.0	*	255.255.255.0	U	vlan10
1.1.1.0	*	255.255.255.0	U	ipsec0
127.0.0.0	*	255.0.0.0	U	lo

Refresh

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 4-19. The view routing table

In Figure 4-19, “Destination” stands for “destination IP address” and “Gateway” stands for “default gateway”. The “Flags” field describes the status of the routing entries. An interface will be denoted by eth0 if it is a LAN interface and eth1 if it is a WAN interface.

4.6.2 View ARP Cache Table

After clicking the **View ARP Cache Table** option, you will see the following Web page as shown in Figure 4-20.

The screenshot shows the Vigor3300 series MultiService Security web interface. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The main content area is titled "System - Diagnostic Tools - View ARP Cache Table". It displays a table with three columns: IP Address, MAC Address, and Interface. The table contains five rows of data. A Refresh button is located at the bottom right of the table.

IP Address	MAC Address	Interface
172.16.2.145	00:0E:A6:2A:D5:BE	eth0
172.16.2.249	00:40:F4:6B:57:61	eth0
172.16.2.222	00:11:2F:D5:D0:2B	eth0
172.16.2.88	00:50:7F:28:6E:1D	eth0
172.16.2.91	00:50:7F:23:48:14	eth0

Figure 4-20. The view ARP cache table option

4.6.3 View DHCP Assignment Table

After clicking the **View DHCP Assignment Table** option, you will see the following Web page as shown in Figure 4-21.

The screenshot shows the Vigor3300 series MultiService Security web interface. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The main content area is titled "System - Diagnostic Tools - View DHCP Assignment Table". It displays a table with three columns: Assigned IP, MAC Address, and Time Left. The table contains one row of data. A Refresh button is located at the bottom right of the table.

Assigned IP	MAC Address	Time Left
192.168.1.10	00:0E:0C:35:E3:EA	11 seconds

Figure 4-21. The view DHCP assignment table option

4.6.4 View NAT Active Sessions Table

After clicking the **View NAT Active Sessions Table** option, you will see the following Web page as shown in Figure 4-22.

Type	Expire in	State	Source IP	Dest IP	sPort	dPort	Rep	Source IP	Rep	Dest IP	sPort	dPort
tcp	591	ESTABLISHED	192.168.1.222	207.46.6.24	3435	1863	207.46.6.24	172.16.2.225	1863	34682		
tcp	598	ESTABLISHED	192.168.1.222	207.46.6.153	3476	1863	207.46.6.153	172.16.2.225	1863	34723		

Page Index : 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

Refresh

Figure 4-22. The view NAT active sessions table option

4.7 Configuration Setup

Most of the settings can be saved locally as a configuration file, which can be applied to another router. The Vigor3300 series supports the restore and upload functions of **configuration files**. In the System group, click the **Configuration Setup** option to bring up the following Web page as shown in Figure 4-23.




Figure 4-23. The configuration setup option

System Setup

After clicking the **Configuration** option, you will see the following setup Web page as shown in Figure 4-24.

Figure 4-24. The configuration file function

Upload	
Select a Configuration File	The location of the configuration file to be uploaded to the router.
Download	
Download Configuration File Push Download Button	Download the configuration file to a local host. The default file name is “v3300.cfg”.

CHAPTER 5

Network Setup

This chapter shows how to setup the router to access the Internet in **WAN** and **LAN** interfaces.

This chapter is divided into the following sections.

- Section 5.1: WAN and Internet Access Setup
- Section 5.2: LAN Setup
- Section 5.3: Load Balance Policy
- Section 5.4: High Availability Setup

5.1 WAN and Internet Access Setup

The Vigor3300 series supports four WAN interfaces, which share the same setting page. These WAN interfaces need to be configured for Internet access. In the **Network** group, click the **WAN** option as shown in Figure 5.1.

Network Setup

The screenshot displays the web management interface for a Vigor3300 series device. The top navigation bar includes tabs for Quick Setup, System, Network (selected), Advanced, Firewall, QoS, VPN, and VoIP. The Network tab is active, and a sub-menu is open showing options: WAN (selected), Load Balance Policy, LAN, and High Availability. The main content area is titled 'System - Status' and contains a 'Refresh Option:' button. Below this is a table with three tabs: Basic Status (selected), LAN Status, and WAN Status. The Basic Status tab displays the following information:

Basic Status	
Model :	Vigor3300V
Hardware Version :	1.0
Firmware Version :	2.5.6 RC3
Build Date&Time :	Tue Sep 13 17:42:00 CST 2005
System Uptime :	4 days 11 hours 4 minutes 18 seconds
CPU Usage :	15.6463%
Memory Usage :	60.4072%
Current System Time :	Tue Sep 27 19:52:51 2005

The footer of the interface reads: DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-1. The WAN option

After clicking the **WAN** option, you will see the following page as shown in Figure 5-2.

Network Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP
8:17:13 P.M.

Network - WAN

Load Balance : ☐ Disable ☒ Enable (☐ Auto Weight)

Backup : ☒ Disable ☐ Enable

#	Edit	IP Mode	Active	Default Route	Load Balance	Weight	Backup-Master	Backup-Slave	VoIP
WAN1		Static	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	50%	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
WAN2		Static	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	30%	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
WAN3		PPPoE	<input checked="" type="checkbox"/>	<input type="radio"/>	<input checked="" type="checkbox"/>	20%	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
WAN4		PPTP	<input type="checkbox"/>	<input type="radio"/>	<input type="checkbox"/>	10%	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Apply Cancel

DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-2. WAN interfaces

Load Balance	“ Enable ” or “ Disable ” the WAN load balance function. The Auto Weight option becomes available if “ Enable ” mode is selected.
Backup	“ Enable ” or “ Disable ” backup function for WAN interfaces.
Edit	Link to configuration page of this WAN interface.
IP Mode	The current mode of this WAN interface. There are four options: <ul style="list-style-type: none"> ● Static ● DHCP ● PPPoE ● PPTP
Active	Activate/deactivate this WAN interface.
Default Route	Set this WAN interface as default route interface.
Load Balance	Add this WAN interface to the load balance group.

Network Setup

Weight	Set the weight load (10-90%) for this WAN interface for load balance.
Backup-Master	Set this WAN interface as a master interface.
Backup-Slave	Set this WAN interface as a slave interface.
VoIP	Set this WAN interface as VoIP default interface.

Note:

If user enables backup function, user has to assign the WAN1 as Master interface absolutely.

Most users will use their routers primarily for Internet access. The Vigor3300 series supports broadband Internet access and provides multiple WAN interfaces. The following sections will give a detailed illustration to broadband access methods.

Click the “**Edit**” icon to bring up the WAN configuration page for the corresponding interface on Figure 5-3.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 10:18:53 A.M.

Network - WAN - WAN1 - Fast Ethernet

MAC Address : ☒ Default MAC ☐ User Defined MAC
00:50:7f:c4:c6

Downstream Rate : 102400 (kbps)

Upstream Rate : 102400 (kbps)

Type : Fast Ethernet

Physical Mode : Auto Negotiation

IP Mode : ☒ Static ☐ DHCP ☐ PPPoE ☐ PPTP

Figure 5-3. WAN interface configuration

MAC Address	
Default MAC	Select the default Mac address.
User Defined MAC	Select a MAC address defined by user.

Downstream Rate	Set downstream rate for this WAN interface. The default value is 102400 kbps (100 Megabit).
Upstream Rate	Set transmission rate for this WAN interface. The default value is 102400 kbps (100 Megabit).
Type	Set connection type for this WAN interface.
Physical Mode	Set connection speed mode. There are five options for Auto negotiation, full duplex, and half duplex , 10M or 100M.
IP Mode	Set IP Mode to Static (fixed IP) , DHCP (dynamic IP address) , PPPoE , or PPTP and creates IP group information. Most cable modem users use DHCP to get a globally reachable IP address from the cable head-end system.

Before you connect a broadband access device e.g. a DSL/Cable modem to the router, you need to know what kind of Internet access your ISP provides. The following sections introduce four widely used broadband access services: **Static**, **PPPoE**, **PPTP** for DSL and **DHCP** for Cable modem. In most cases, you will get a DSL or cable modem from the broadband access service provider. The router is connected behind the broadband device i.e. DSL/cable modem and works as a NAT or IP router for broadband connections.

5.1.1 Static IP Setup

The IP group information for each WAN interface can be manually assigned by the user and shown in Figure 5-4.

Network Setup

Static/DHCP Configuration		PPPoE/PPTP Configuration	
IP Address :	<input type="text" value="172.16.2.225"/>	Host Name :	<input type="text" value="hinet"/>
Subnet Mask :	<input type="text" value="255.255.255.0"/>	Domain Name :	<input type="text" value="hinet.net"/>
Default Gateway :	<input type="text" value="172.16.2.233"/>	(Host Name and Domain Name are required for some ISPs.)	
Primary DNS :	<input type="text" value="168.95.1.1"/>		
Secondary DNS :	<input type="text" value="168.95.192.1"/>		
Connection Detection			
Detect Type :	<input type="text" value="Send PING"/>		
Detect Interval(sec) :	<input type="text" value="10"/>		
Max Unreply Times:	<input type="text" value="4"/>		
Detect Destination Host : (IP or Domain Name)	<input type="text" value="172.16.2.233"/>		
IP Alias List			
1.	<input type="text" value="10.1.1.100"/>	2.	<input type="text" value="10.1.1.104"/>
3.	<input type="text" value="10.1.1.101"/>	4.	<input type="text" value="10.1.1.105"/>
5.	<input type="text" value="10.1.1.102"/>	6.	<input type="text" value="10.1.1.106"/>
7.	<input type="text" value="10.1.1.103"/>	8.	<input type="text" value="10.1.1.107"/>
<input type="button" value="Apply"/> <input type="button" value="Reset"/> <input type="button" value="Cancel"/>			

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-4. Static IP configuration

IP Address	Sets the private IP address of WAN interface.
Subnet Mask	Sets the subnet mask value of WAN interface.
Default Gateway	Sets the private IP address of gateway.
Primary DNS	Sets the private IP address of primary DNS.
Secondary DNS	Sets the private IP address of secondary DNS.
Connection Detection	
Detect Type	Select a detecting type for this WAN interface. There are three ways “ARP”, “PING” and “HTTP” supported in 3300.
Detect Interval(sec)	Assign an interval period of time for each detecting.
Max Unreply Times	Assign detecting times to ensure the connection of the WAN.
Detect Destination Host (IP or Domain Name)	Assign an IP address or Domain name as a destination to be detected.
IP Alias List	Sets other IP addresses binding in this interface.

Click **Apply** to go back to the WAN Interface Configuration page as shown in Figure 5-3. To apply all settings, click **Apply** on the WAN Interface Configuration page and reboot your router when prompted.

5.1.2 DHCP Client Setup

If the WAN interface is set as a DHCP client, the Vigor3300 will ask for IP network settings from the DHCP server or DSL modem automatically. It is not necessary for the user to manually configure the router on Figure 5-5.

Static/DHCP Configuration		PPPoE/PPTP Configuration	
IP Address :	<input type="text" value="172.16.2.225"/>	Host Name :	<input type="text" value="hinet"/>
Subnet Mask :	<input type="text" value="255.255.255.0"/>	Domain Name :	<input type="text" value="hinet.net"/>
Default Gateway :	<input type="text" value="172.16.2.233"/>	(Host Name and Domain Name are required for some ISPs.)	
Primary DNS :	<input type="text" value="168.95.1.1"/>		
Secondary DNS :	<input type="text" value="168.95.192.1"/>		
Connection Detection			
Detect Type :	<input type="text" value="Send PING"/>		
Detect Interval(sec) :	<input type="text" value="10"/>		
Max Unreply Times:	<input type="text" value="4"/>		
Detect Destination Host : (IP or Domain Name)	<input type="text" value="172.16.2.233"/>		
IP Alias List			
1.	<input type="text" value="10.1.1.100"/>	2.	<input type="text" value="10.1.1.104"/>
3.	<input type="text" value="10.1.1.101"/>	4.	<input type="text" value="10.1.1.105"/>
5.	<input type="text" value="10.1.1.102"/>	6.	<input type="text" value="10.1.1.106"/>
7.	<input type="text" value="10.1.1.103"/>	8.	<input type="text" value="10.1.1.107"/>

Apply Reset Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-5. DHCP configuration

Click **Apply** to go back to the WAN Interface Configuration page as shown in Figure 5-3. To apply all settings, click **Apply** on the WAN Interface Configuration page and reboot your router when prompted.

5.1.3 PPPoE with a DSL Modem Setup

Most DSL modem users use this mode. All local users can share one PPPoE connection to access the Internet as shown in Figure 5-6.

Figure 5-6. PPPoE configuration

User Name	Assign a specific valid user name provided from a local ISP.
Password	Assign a valid password provided from a local ISP.
Authentication	Select PAP or CHAP protocol for widest compatibility. The default value is PAP .
Service Name	Assign a service name required from ISP service.
Connection Detection	
Detect Interval	Assign an interval time for detecting.
Max Unreply Times	Assign detecting times to ensure the connection of WAN.

Click **Apply** to go back to the WAN interface configuration page as shown in Figure 5-3. To apply all settings, click **Apply** on the WAN interface configuration page and reboot your router when prompted.

5.1.4 PPTP with a DSL Modem Setup

The following setup page is just an example on Figure 5-7. Your service provider should provide the exact settings.

Figure 5-7. PPTP configuration

PPTP Local Address	Assign a local IP address.
PPTP Subnet Mask	Assign a subnet mask value of IP address.
PPTP Remote Address	Assign a remote IP address of PPTP server.

Click **Apply** to go back to the WAN Interface Configuration page as shown in Figure 5-3. To apply all settings, click **Apply** on the WAN Interface Configuration page and reboot your router when prompted.

5.2 LAN Setup

In this section, we will explain more details on the **LAN** interface setup.

In the **Network** group, click **LAN** option as shown in Figure 5-8.




Figure 5-8. The LAN option

After clicking the **LAN** option, you will see the following page as shown in Figure 5-9.

Network Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 8:11:29 P.M.

Network - LAN

IP Configuration 1st DHCP Server 2nd DHCP Server

For NAT Usage

1st IP Address : 192.168.1.111

1st Subnet Mask : 255.255.255.0

For IP Routing Usage

☐ Enable ☒ Disable

2nd IP Address :

2nd Subnet Mask :

WAN Interface : WAN1

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-9. LAN configuration

There are three options:

***IP Configuration**

***1st DHCP Server**

***2nd DHCP Server**

5.2.1 IP Configuration

After clicking **IP Configuration**, you will see the following page as shown in Figure 5-10.

The screenshot shows the web interface of a Vigor3300 series MultiService Security router. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The 'Network' tab is selected, and the 'IP Configuration' sub-tab is active. The page is titled 'Network - LAN'. Under 'For NAT Usage', the '1st IP Address' is set to 192.168.1.1 and the '1st Subnet Mask' is set to 255.255.255.0. Under 'For IP Routing Usage', the 'Enable' radio button is selected, and the '2nd IP Address' and '2nd Subnet Mask' fields are empty. The 'WAN Interface' is set to WAN1. At the bottom right, there are 'Apply' and 'Cancel' buttons. The footer contains the text: 'DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 5-10. IP configuration

In the Vigor3300 router, there are some IP address settings for the LAN interface as shown below. The IP address/subnet mask is for private users or NAT users. To allow public users, you need to subscribe to a globally reachable subnet from your ISP. The IP address of the default gateway on other local PCs should be set as the Vigor3300's server IP address. When the DSL connection between the DSL and the ISP has been established, each local PC can directly route to the Internet. The IP address/subnet mask can also be used to connect to other private users (PCs). On the page you will see the private IP address defined in RFC-1918. Usually we use the 192.168.1.0/24 subnet for the route.

Network Setup

NAT Usage	
1st IP Address	The first private IP address connecting to a local private network. The default value is 192.168.1.1.
1st Subnet Mask	The subnet mask value of the first private IP address connecting to a local private network. The default value is 255.255.255.0.
IP Routing Usage	
Status	“ Enable ” IP Routing Usage. “ Disable ” IP Routing Usage.
2nd IP Address	Assign an IP address belongs to the subnet of the WAN selected in WAN Interface field.
2nd Subnet Mask	The value of subnet mask.
WAN Interface	Select a WAN interface to be applied in IP Routing Usage.

Click **Apply** to reboot the system and apply the settings.

5.2.2 1st DHCP Server Configuration

The Vigor3300 series supports two DHCP servers.

DHCP stands for Dynamic Host Configuration Protocol. It acts as DHCP client and can automatically dispatch related IP settings from DHCP server. Please refer to the following picture for DHCP server configuration.

After clicking the **1st DHCP Server** option, you will see the following page as shown in Figure 5-11.

Network Setup

The screenshot shows the web interface of a Vigor3300 series MultiService Security device. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The 'Network' tab is selected, and the '1st DHCP Server' sub-tab is active. The configuration page is titled 'Network - LAN'. It contains two main sections: 'IP Configuration' and 'Relay Agent'. In the 'IP Configuration' section, the 'Status' is set to 'Enable' (radio button selected). The 'Start IP' is 192.168.1.10, 'End IP' is 192.168.1.254, 'Primary DNS' is 168.95.1.1, 'Secondary DNS' is empty, 'Lease Time (Min)' is 1400, and 'Gateway IP(Optional)' is empty. The 'Relay Agent' section shows 'WAN Interface' set to 'WAN1' and 'DHCP Server IP Address' is empty. 'Apply' and 'Cancel' buttons are at the bottom right. A footer note states: 'DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 5-11. 1st DHCP server configuration

Status	“Enable” the first DHCP server. “Disable” the first DHCP server.
Start IP	Set the starting IP address of the IP address pool.
End IP	Set the ending IP address of the IP address pool.
Primary DNS	Sets the private IP address of the primary DNS.
Secondary DNS	Sets the private IP address of the secondary DNS.

Click **Apply** to reboot the system and apply the settings.

Note:

If both the Primary and Secondary DNS fields are left empty, the router will assign its own IP Address to local users as a DNS proxy server and maintain a DNS cache. If the IP address of a domain name is already in the DNS cache, the router will resolve the domain name immediately. Otherwise, the router forwards the DNS query packet to the external DNS server by establishing a WAN (e.g. DSL/Cable) connection.

5.2.3 2nd DHCP Server Configuration

The Vigor3300 supports a second DHCP server function for users. After clicking the 2nd DHCP Server option, you will see the following web page on Figure 5-12. Users can the 2nd DHCP feature to assign a specific PC to related IP in the IP address pool.

Vigor3300 series .
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 7:29:52 P.M.

Network - LAN

IP Configuration 1st DHCP Server **2nd DHCP Server**

Start IP Address : 192.168.1.10

IP Pool Size : 10

MAC Address List (MAC Address Format xx:xx:xx:xx:xx:xx)

1.	00:00:0a:00:00:01	2.	00:00:0a:00:00:02
3.	00:00:0a:00:00:03	4.	00:00:0a:00:00:04
5.	00:00:0a:00:00:05	6.	00:00:0a:00:00:06
7.	00:00:0a:00:00:07	8.	00:00:0a:00:00:08
9.	00:00:0a:00:00:09	10.	00:00:0a:00:00:0a

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-12. 2nd DHCP server configuration

Network Setup

<i>Start IP Address</i>	Set the starting IP address of the IP address pool.
<i>IP Pool Size</i>	Assign the number how many IP addresses in the pool.
<i>Mac Address List</i>	Sets 10 Mac addresses to be served. Once the Mac address is matched in this table, the router can get IP address group information.

Click **Apply** to reboot the system and apply your settings.

5.3 Load Balance Policy

The Vigor3300 supports a load balancing function. This function can assign traffic with protocol type, IP address for specific host, a subnet of hosts, and port range to be allocated in WAN interface. User can assign traffic category and force these traffic to go to dedicate network interface based on the following web page setup. VoIP and VPN traffic can also be assigned to specific WAN ports.

In the **Network** group, click the **Load Balance Policy** option as shown in Figure 5-13.




Figure 5-13. The load balance policy option

Network Setup

After clicking the **Load Balance Policy** option, you will see the following web page as shown in Figure 5-14.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System **Network** Advanced Firewall QoS VPN VoIP 1:29:57 P.M.

Network - Load Balance Policy

#	Protocol	Source IP	Subnet Mask	Dest IP	Subnet Mask	Dest Port Start	Dest Port End	Network Interface
1	<input checked="" type="radio"/>							
2	<input type="radio"/>							
3	<input type="radio"/>							
4	<input type="radio"/>							
5	<input type="radio"/>							
6	<input type="radio"/>							
7	<input type="radio"/>							
8	<input type="radio"/>							
9	<input type="radio"/>							
10	<input type="radio"/>							

1

Edit Delete Delete All

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-14. Load balance policy table

Network Setup

To edit an entry, select it by clicking the radio button. Then click the **Edit** option to bring up the following Web page as shown in Figure 5-15.

Figure 5-15. Edit load balance policy entry

Protocol	Select the desired protocol.
Source IP/Subnet Mask	Assign a source IP address or a subnet.
Dest IP/Subnet Mask	Assign a destination IP address or a subnet.
Dest Port Range	Assign a destination port number range.
Network Interface	Select an interface to be forwarded to.

Click **Apply** to add or modify this entry into the Load Balance Policy table.

Network Setup

To delete an entry, select by clicking the radio button. Then click the **Delete** option to bring up the following Web page as shown in Figure 5-16.




Figure 5-16. Delete load balance policy entry

Click **Delete** to delete this entry from the Load Balance Policy table.

Click **Delete All** in the Load Balance Policy page (Figure 5-14) to delete all 10 entries on the page.

5.4 High Availability Setup

The High Availability (HA) feature refers to the availability of resources in the wake of component failures in the system. The complexity of a high availability solution to provide constant service is determined by a company's availability needs and by the amount of system interruptions that can be tolerated by a business. Any hardware or software components in the system will fail to have a redundant component to backup. Systems that can provide nearly full-time availability typically have redundant hardware and software that makes the system available despite failures. The high availability of the V3300 series is designed to avoid single points-of-failure. When failures occur, the failover process moves processing performed by the failed component (the "Master") to the backup component (the "Slave"). This process remains system-wide resources, recovers partial of failed transactions, and restores the system to normal within a matter of microseconds.

Take the following picture as an example. The left V3300 is Master, the right V3300 is Slave. When Master V3300 is broken down, the Slave V3300 could replace the Master role to take over all jobs as soon as possible. However, once the original Master is working again, the Slave would be changed to original role to stand by.

Network Setup




Figure 5-17. High availability application scenario

Network Setup

Please refer to the following web page in Figure 5-18.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 6:28:02 P.M.

Network - LAN - High Availability

High Availability: ☐ Disable ☒ Enable

Group Number: (Range: 1~255)

Role:

Virtual IP:

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 5-18. High availability configuration

High Availability	“Disable” or “Enable” this function.
Group Number	Assign a group number, the range is from 1 to 255.
Role	Select a role as Master or Slave.
Virtual IP	Assigns an IP address as a virtual IP.

Click **Apply** to reboot the router and apply the settings.

CHAPTER 6

Advanced Setup

This chapter shows how to configure Advanced functions.

This chapter is divided into the following sections:

- Section 6.1: Static Route Setup
- Section 6.2: NAT Setup
- Section 6.3: Port Block Setup
- Section 6.4: UPnP Setup
- Section 6.5: DDNS Setup
- Section 6.6: RADIUS Setup
- Section 6.7: Call Schedule Setup
- Section 6.8: WAN Port Mirroring Setup
- Section 6.9: LAN Port Mirroring Setup
- Section 6.10: LAN VLAN Setup
- Section 6.11: SNMP

6.1 Static Route Setup

The **Static Route** function allows users to assign static routing information. In the **Advanced** group, click the **Static Route** option as shown in Figure 6-1.

Advance Setup




Figure 6-1. The static route option

After clicking the **Static Route** option, you will see the following web page as shown in Figure 6-2.



Figure 6-2. Static route table

6.1.1 Edit Option

Click **Edit** to add or edit an entry in the static route table as shown in Figure 6-3.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network **Advanced** Firewall QoS VPN VoIP 9:40:37 A.M.

Advanced - Static Route - Edit

1	Network Interface :	WAN1
	Gateway IP :	172.16.2.233
	Destination IP :	202.66.88.99
	Subnet Mask :	/24

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-3. Edit option

Network Interface	Select a network interface as a destination to be sent. It includes LAN, WAN1~WAN4.
Gateway IP	Assign an IP address of the gateway within the interface selected in Network Interface field.
Destination IP	Assign the destination IP address to be checked.
Mask	Assign a value of subnet mask for destination IP address.

Click **Apply** to finish settings.

6.1.2 Delete option

Click **Delete** button to remove an entry in the static route table then the following window will be popped-up as shown in Figure 6-4.




Figure 6-4. Delete option

Click **OK** to delete the entry in static route table.

Before execute the **Edit** or **Delete** options, the user has to click the radio box belonging to each index number.

User can click **Delete All** to remove all entries in static route table.

6.2 NAT Setup

NAT (Network Address Translation) is a method of mapping one or more IP addresses and/or service ports into different specified services. It allows the internal IP addresses of many computers on a LAN to be translated to one public address to save on costs and resources of multiple public IP addresses. It also plays a security role by obscuring the true IP addresses of important machines from potential hackers on the Internet. The Vigor 3300 is NAT-enabled by default and gets one globally routable IP addresses from the ISP by Static, PPPoE, or DHCP mechanism. The Vigor3300 series assigns private network IP addresses according to RFC-1918 protocol and will translate the private network addresses to a globally routable IP address so that local hosts can communicate with the router and access the Internet.

In the **Advanced** group, click the **NAT** option to bring up the following setup page as shown in Figure 6-5.




Figure 6-5. NAT functions

6.2.1 Port Redirection Table Setup

The **Port Redirection Table** may be used to expose internal servers to the public domain or open a specific port to internal hosts. Internet hosts can use the WAN IP address to access internal network services, such as FTP, WWW, etc. The following example shows how an internal FTP server is exposed to the public domain. The internal FTP server is running on the local host addressed as 192.168.1.2. A user can also translate the port to another port by configuration. The packet is forwarded to a specific local host if the port number matches that defined in the table.

Click **Port Redirection** option, and then you will see the following setup page. Figure 6-6 illustrates the web page as an example.

Advance Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick SetupSystemNetworkAdvancedFirewallQoSVPNVoIP5:14:54 P.M.

Advanced - NAT - Port Redirection

#	Comment	Protocol	Public Port Start	Public Port End	Private IP	Private Port Start	Private Port End	Use IP Alias	WAN Interface	IP Alias
1	<input checked="" type="radio"/>									
2	<input type="radio"/>									
3	<input type="radio"/>									
4	<input type="radio"/>									
5	<input type="radio"/>									
6	<input type="radio"/>									
7	<input type="radio"/>									
8	<input type="radio"/>									
9	<input type="radio"/>									
10	<input type="radio"/>									

1

EditDeleteDelete All

Figure 6-6. NAT-Port redirection information page

Click **Edit** to add a new rule entry or modify an existed rule entry. Figure 6-7 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 8:14:42 P.M.

Advanced - NAT - Port Redirection - Edit

1

Comment : a

Protocol : TCP

Public Port Range: 200 - 600

Private IP : 192.168.3.100

Private Port Range: 200 - 600

Use IP Alias : ☒ Disable ☐ Enable

WAN Interface : WAN1

IP Alias : 10.1.1.100

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-7. Edit a new entry

Comment	Assign a name of this entry.
Protocol	Assign the transport layer protocol with TCP or UDP .
Public Port Range	Assign a port range from starting to end public port number.
Private IP	Assign a local IP address to be transferred into.
Private Port Range	Assign a port range from starting to end private port number.
Use IP Alias	“ Disable ” option uses IP address of WAN interface, “ Enable ” option uses IP alias addresses.
WAN Interface	It is a pull-down window; user can select one specific WAN interface.
IP Alias	It is a pull-down window; user can select one specific IP address assigned in IP Alias group of WAN interfaces.

Click **Apply** to finish this setting.

Note:

The port forwarding function could redirect the Internet traffic, which has the destination port within the public port range and has the same IP address as “WAN Interface” or “IP Alias” you set. Please redirect only the ports you know you have to forward rather than forward all ports. Otherwise, the intrinsic firewall type security of NAT facility will be affected.

By the way, user can click **Delete** to remove one current existed NAT entry and click **Delete All** to remove all entries.

6.2.2 Address Mapping Setup

If you have a group of static IP addresses, then you can use the address-mapping feature to multiple open ports hosts in the Vigor3300 series of broadband security routers. The following session will show you how to setup address-mapping feature.

In the **Advance** group, click **NAT** option. Then you will see the following setup page. Figure 6-8 illustrates the location of **Address Mapping** option.

Advance Setup




Figure 6-8. NAT-Address mapping option

Click **Address Mapping** option, then you will see the following web page. Figure 6-9 illustrates the web page as an example.




Figure 6-9. NAT-Address mapping information page

DrayTek

Click **Edit** to add a new rule entry or modify an existed rule entry. Figure 6-10 illustrates the web page as an example.

Figure 6-10. Edit a new entry in address mapping

Protocol	Select the transport layer protocol. It could be TCP, UDP, or All for selection.
Public IP	Select an IP address from IP Alias in WAN interface. Local host can use this IP to connect to the Internet.
Private IP	Assign an IP address or a subnet to be compared with the source IP address for incoming packets.
Subnet Mask	Select a value of subnet mask for private IP address.

Click **Apply** to finish this setting.

By the way, user can click **Delete** to remove a current existed NAT entry and click **Delete All** to remove all entries.

6.2.3 DMZ Host

In computer networks, a DMZ (De-Militarized Zone) is a computer host or small network inserted as a neutral zone between a company's private network and the outside public network. It prevents outside users from getting direct access to company network. A DMZ is an optional and more secure approach to a firewall and effectively acts as a proxy server as well. In a typical DMZ configuration for a small company, a separate computer (or host in network terms) receives requests from users within the private network for access to Web sites or other companies accessible on the public network. The DMZ host then initializes sessions for these requests on the public networks. However, the DMZ host is not able to initiate a session back into the private network. It can only forward packets that have already been requested. Users of the public network outside the company can access only the DMZ host. The DMZ may typically also have the company's Web pages so these could be served to the outside world. If an outside user penetrated the DMZ host's security, only the Web pages might be corrupted but other company information would not be exposed.

In the **Advanced** group, click **NAT** option. Then you will see the following page. Figure 6-11 illustrates the location of **DMZ Host** option.

Advance Setup




Figure 6-11. DMZ host option

Click **DMZ Host**, and then you will see the following page. Figure 6-12 illustrates the web page as an example.




Figure 6-12. DMZ host table

DrayTek

Advance Setup

Click **Edit** to add a new entry in DMZ Host table. Figure 6-13 illustrates the web page as an example.

Figure 6-13. DMZ host – edit

WAN Interface	Select a WAN interface
Private IP	Assign an IP address of DMZ server to be permitted for access from outside.
Use IP Alias	“ Disable ” option uses WAN interface, “ Enable ” option uses IP Alias addresses.
IP Alias	Select an IP address within the list of IP Alias configured in WAN interface.

Click **Apply** to finish this setting.

Advance Setup

Click **Delete** to remove an existed entry in DMZ Host table. Figure 6-14 illustrates the web page as an example.




Figure 6-14. DMZ host – delete

Click **Apply** to finish this setting.

User can click **Delete All** to remove all entries in the table.

6.3 Port Block Setup

The **Port Block** function provides a user to set lots of proprietary port numbers. Packets will be dropped if destination ports (Both TCP and UCP) of packets with these assigned port numbers both on WAN and LAN. The advantage of this feature is to filter some unnecessary packets or attacking packets on Internet environment or LAN network. The Vigor3300 series supports ten port numbers¹ to be blocked.

In the **Advanced** group, click **Port Block** option. Figure 6-15 illustrates the location of the **Port Block** option.




Figure 6-15. Port block option

Click the **Port Block** option, and then you will see the following web page.

¹ Vigor3300V model does not support default values.

Figure 6-16 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup

System

Network

Advanced

Firewall

QoS

VPN

VoIP

8:50:15 P.M.

Advanced - Port Block

Index	Status	Port Number
1.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
2.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
3.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
4.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
5.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
6.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
7.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
8.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
9.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>
10.	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	<input type="text"/>

Apply

Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-16. Port block configuration

Index	The number of each entry.
Status	User can “Disable” or “Enable” this port to be blocked
Port Number	Assign a port number to be blocked in system.

Click **Apply** to finish this setting. The default port setting for V3300B, 3300B+ is 135, 137, 138, 139, and 445.

6.4 UPnP Setup

The UPnP (Universal Plug and Play) protocol aims at the plug and play of network devices. Such a feature is already available for directly connected PC peripherals in Windows 'Plug and Play' system. For NAT routers, the major feature of UPnP on the Vigor3300 router is “NAT Traversal”, which means that applications inside firewall could open ports to penetrate router automatically. Such a mechanism is more feasible than relying on the router to allocate open ports by itself. Further, the user does not have to manually setup port mappings or a DMZ.

In the **Advanced** group, click **UPnP** option. Figure 6-17 illustrates the location of **UPnP** option.




Figure 6-17. UPnP option

With the UPnP feature employed, the Vigor3300 series provide voice, video and messaging communication of MSN Messenger for user on Windows XP.

Advance Setup

Click **UPnP option**, and then you will see the following web page. Figure 6-18 illustrates the web page as an example.

Figure 6-18. UPnP configuration

Enable/Disable	Click the round box to Disable or Enable UPnP function.
Network Interfaces	Select a specific WAN interface for UPnP.

Click **Apply** to finish this setting.

Click the **IP Broadband Connection on DrayTek Router** on Windows XP/Network Connections, as shown as Figure 6-19. The connection status and control status will be able to be activated.




Figure 6-19. Windows network connection

The NAT Traversal feature of UPnP enables multimedia feature of your applications. Without UPnP, you will have to set up port mappings or do some similarly configurations manually.

Figure 6-20, 6-21 illustrate the web page as an example.




Figure 6-20. Connection status

DrayTek




Figure 6-21. UPnP configuration

The Vigor3300 UPnP facility triggers UPnP-sensitive applications inside NAT such as MSN Messenger to discover the external IP address and configure port mappings on router. As a result, router with UPnP facility will redirect packets from the external ports to the internal ports according to application's requirement.

6.5 DDNS Setup

The Dynamic DNS function allows the router to update its online WAN IP address, which assigned by ISP or other DHCP server to the specified Dynamic DNS server. Once the router is online, you will be able to use the registered domain name to access the router or internal virtual servers from the Internet. DDNS is more popular on dynamic IP users, who typically receive dynamic, frequently-changing IP addresses from their service provider.

Before you set up the Dynamic DNS function, you have to subscribe free domain names from the Dynamic DNS service providers. The router provides up to ten accounts for the function and supports the following providers: www.dynsns.org, www.no-ip.com, www.dtdns.com, www.changeip.com, www.ddns.cn. You should visit their websites for registering your own domain name on the router.

In the **Advanced** group, click **DDNS** option. Figure 6-22 illustrates the location of **DDNS** option.




Figure 6-22. DDNS option

Click the **DDNS** option, and then you will see the following web page. Figure 6-23 illustrates the web page as an example.

Advance Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP 1:52:04 P.M.

Advance - DDNS

#	Domain Name	Server Provider	Server Type	Active	Status
1		dyndns.org	dynamic	disable	Not Connected
2		dyndns.org	dynamic	disable	Not Connected
3		dyndns.org	dynamic	disable	Not Connected
4		dyndns.org	dynamic	disable	Not Connected
5		dyndns.org	dynamic	disable	Not Connected
6		dyndns.org	dynamic	disable	Not Connected
7		dyndns.org	dynamic	disable	Not Connected
8		dyndns.org	dynamic	disable	Not Connected
9		dyndns.org	dynamic	disable	Not Connected
10		dyndns.org	dynamic	disable	Not Connected

Refresh

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-23. DDNS table

Click **Refresh** to re-display the whole page information. Click **#number** into edit mode to modify an entry in DDNS table. Figure 6-24 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 8:35:51 P.M.

Advanced - DDNS Setting

Status : ☐ Disable ☒ Enable

Interface :

Server Provider :

Server Type :

Domain Name :

Login Name :

Login Password :

Wild Card : ☒ Disable ☐ Enable

Backup MX : ☒ Disable ☐ Enable

Mail Extender :

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-24. DDNS configuration

Status	Click “ Disable ” to disable this function. Click “ Enable ” to activate this function.
Interface	Select a specific interface for registering on DDNS server. The Interface should be any WAN port on V3300 series.
Server Provider	Assign a provider name to support DDNS server. The Vigor3300 supports 4 domain server providers as default.
Server Type	Select Static , Dynamic or Custom type.
Domain Name	Assign a private domain name to be accessed.
Login Name	Assign a name to login into DDNS server.
Login Password	Assign a password to login into DDNS server.
Wild Card	If you want anything-here.yourhost.dyndns.org to work (EX. To make things like <u>www.yourhost.dyndns.org</u> work), click “Enable” to active this function.
Backup MX³	MX stands for Mail Exchanger. Mail Exchangers are used for directing mail to specific servers other than the one a hostname points at.
Mail Extender	Assign an email address.

Click **Apply** to finish this setting. Figure 6-25 illustrates the web page as an example.

² The Wildcard and Backup MX features are not supported for all Dynamic DNS providers. You could get more detailed information from their websites.

³ Backup MX provides a secondary mail server to hold your e-mail if your main email server go offline for any reason. Once you go back online, your email will be delivered to you.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup
System
Network
Advance
Firewall
VPN
VoIP

Advance - DDNS

#	Domain Name	Server Provider	Server Type	Active
1	abc.dyndns.org	dyndns.org	dynamic	enable
2		dyndns.org	dynamic	disable
3		dyndns.org	dynamic	disable
4		dyndns.org	dynamic	disable
5		dyndns.org	dynamic	disable
6		dyndns.org	dynamic	disable
7		dyndns.org	dynamic	disable
8		dyndns.org	dynamic	disable
9		dyndns.org	dynamic	disable
10		dyndns.org	dynamic	disable

DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-25. DDNS table

6.6 RADIUS Setup

A RADIUS (Remote Authentication Dial-In User Service) is a security authentication client/server protocol widely used by Internet service providers on other remote access service. A RADIUS is the most common means of authenticating and authorizing dial-up and tunneled network users. The built-in RADIUS client function allows you to extend the remote dial-in user accounts to the RADIUS server. Your user accounts will not be limited by built-in accounts. It also lets you centralize remote access authentication for network management. Radius is a server for remote user authentication and accounting. Its primary use is for Internet Service Providers, though it may as well be used on any network that needs a centralized authentication and/or accounting service. A Radius supports a wide variety of authentication schemes. A user supplies his authentication data to the server either directly by answering the terminal server's login/password prompts, or using PAP or CHAP protocols. The server obtains the user's personal data from one of the following places.

Advance Setup

The Vigor 3300 series of routers support Radius client function. A user can configure some authentication information to do an authentication with Radius server. In the Vigor 3300, it is only used in VPN->PPTP function.

In the **Advanced** group, click the **Radius** option. Figure 6-26 illustrates the location of the **Radius** option.




Figure 6-26. Radius option

Click **Radius** option, and then you will see the following web page. Figure 6-27 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 8:40:57 P.M.

Advanced - RADIUS

☐ Disable ☒ Enable

Server IP Address : 69.14.100.1

Destination Port : 1812

Shared Secret :

Confirm Shared Secret :

WAN Interface : WAN1

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-27. Radius configuration

Enable/Disable	Click “Disable” to disable this function. Click “Enable” to activate this function.
Server IP Address	Assign an IP address of a Radius server.
Destination Port	Assign a destination port number used for Radius function.
Shared Secret	Assign a code for authentication to server.
Confirm Shared Secret	Confirm the code assigned in Shared Secret field.
WAN Interface	Select one specific WAN interface to be used.

Click **Apply** to finish this setting.

6.7 Call Schedule Setup

These call schedule profiles will control the up or down time of the router’s dialer or connection manager. In order to do the proper call schedule function, a user must have to setup time function and arrange schedules for specified Internet access profile or LAN-to-LAN profile. The Vigor 3300 series of routers support lots of profiles for call schedule usage.

In the **Advanced** group, click the **Call Schedule** option. Figure 6-28 illustrates the location of the **Call Schedule** option.




Figure 6-28. Call schedule option

Click the **Call Schedule** option, and then you will see the following web page. Figure 6-29 illustrates the web page as an example.




Figure 6-29. Call schedule configuration

6.7.1 Edit Option

Click **Edit** to add or edit one entry in call schedule table. Figure 6-30 illustrates the web page as an example.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP

Advance - Call Schedule - Edit

☐ Disable ☒ Enable

Start Date : 2004 - 12 - 28 (Year - Month - Date)

Start Time : 00 : 00 (Hour : Minute)

Action : ☐ force down ☒ force on

How often : ☒ Once ☐ Weekdays

☐ Monday ☐ Tuesday ☐ Wednesday ☐ Thursday ☐ Friday ☐ Saturday ☐ Sunday

Network Interface : WAN1

Apply Cancel

DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-30. Edit call schedule table

Enable/Disable	Click “ Disable ” to disable this function. Click “ Enable ” to activate this function.
Start Date	Assign a date for starting this profile.
Start Time	Assign a time for starting this profile.
Action	“ Force down ” means to inactivate the Network Interface. “ Force up ” means to activate the Network Interface.
How often	“ Once ” means only for one time. “ Weekdays ” means that user can select some weekdays to apply.
Network Interface	Select one specific WAN interface to be applied.

Click **Apply** to finish this setting.

6.7.2 Delete Option

Click **Delete** to remove a profile entry in call schedule table. Figure 6-31 illustrates the web page as an example.




Figure 6-31. Call schedule - delete

Click **Apply** to finish this setting.

User can click **Delete All** to remove all entries in the table.

6.8 WAN Port Mirroring Setup

3300V supports port mirroring function in four WAN interfaces. Generally speaking, this function copies traffic from one or more specific ports to a target port. This mechanism helps user track the network errors or abnormal packets transmission without interrupting the flow of data access the network. By the way, user can apply this function to monitor all traffics which user needs to check.

There are some advantages supported in this feature. Firstly, it is more economical without other detecting equipments to be set up. Secondly, it may be able to view traffic on one or more ports within a VLAN at the same time. Thirdly, it can transfer all data traffics to be mirrored to one analyzer connect to the mirroring port. Last, it is more convenient and easy to configure in user interface.

In the **Advanced** group, click the **WAN Port Mirroring** option as shown in Figure 6-32.



Figure 6-32. WAN port mirroring configuration

Click **Apply** to finish this setting.

Advance Setup

<i>Enable/Disable</i>	Click “ Disable ” to disable this function. Click “ Enable ” to activate this function.
<i>Mirroring Port</i>	Select a port to view traffic sent from mirrored ports.
<i>Mirrored Port(s)</i>	Click which ports are necessary to be mirrored.

6.9 LAN Port Mirroring Setup

We still support the port mirroring function in LAN site not only in WAN site. It has the same mechanism like WAN port mirroring.

In the **Advanced** group, click the **LAN Port Mirroring** option as shown in Figure 6-33.

Figure 6-33. LAN port mirroring configuration

Click **Apply** to finish this setting.

Enable/Disable	Click “ Disable ” to disable this function. Click “ Enable ” to activate this function.
Mirroring Port	Select a port to view traffic sent from mirrored ports.
Mirrored Port(s)	Click which ports are necessary to be mirrored.

6.10 LAN VLAN Setup

3300 supports VLAN function in only in LAN site. Basically, it is only implemented by port-based. User can select some ports to add into a VLAN group. In one VLAN group, the port number can be single one or more.

The purpose of VLAN is to isolate traffic between different users and it can provide better security application.

In the **Advanced** group, click the **LAN VLAN** option as shown in Figure 6-34.

	P1	P2	P3	P4
VLAN0	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
VLAN1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
VLAN2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
VLAN3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Figure 6-34. LAN VLAN configuration

Click **Apply** to finish this setting.

Click **Reset** to reset the VLAN setting as default.

Advance Setup




Figure 6-35. LAN VLAN configuration-Reset

6.11 SNMP Configuration

The Simple Network Management Protocol (SNMP) is an application layer protocol that facilitates the exchange of management information between network devices. There is a set of protocols for managing complex networks. SNMP works by sending messages, called protocol data units (PDUs), to different parts of a network. SNMP enables network administrators to manage network performance, find and solve network problems, and plan for network growth.

A SNMP-managed network consists of three key components, managed devices, agents, and network-management systems (NMSs).

A managed device is a network node that contains an SNMP agent and that resides on a managed network. Managed devices collect and store management information and make this information available to NMSs using SNMP. Managed devices, sometimes called network elements, can be routers and access servers, switches and bridges, computers hosts, or printers.

An agent is a network-management software module that resides in a managed device. An agent has local knowledge of management information and translates that information into a form compatible with SNMP.

A NMS executes applications that monitor and control managed devices. NMSs provide the bulk of the processing and memory resources required for network management. One or more NMSs must exist on any managed network.

In the **Advanced** group, click the **SNMP** option as shown in Figure 6-36.




Figure 6-36. The location of SNMP

6.11.1 SNMP Community

This function is to define a community string name. Generally speaking, NMSs which is within the community are said to exist within the same administrative domain. Community names serve as a weak form of authentication because devices that do not know the proper community name are precluded from SNMP operations.

Click **SNMP Community** option, the page is shown as Figure 6-37.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 7:44:46 P.M.

EMS - SNMP Community

#	Community	Host/mask	Max Access
1	<input checked="" type="radio"/>		
2	<input type="radio"/>		
3	<input type="radio"/>		
4	<input type="radio"/>		
5	<input type="radio"/>		
6	<input type="radio"/>		
7	<input type="radio"/>		
8	<input type="radio"/>		
9	<input type="radio"/>		
10	<input type="radio"/>		

1

Edit Delete Delete All

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-37. SNMP community configuration

Click **Edit** button, the page is shown in Figure 6-38.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network **Advanced** Firewall QoS VPN VoIP 7:57:26 P.M.

EMS - SNMP Community - Edit

1	Community : <input checked="" type="radio"/> Public <input type="radio"/> Private
	Host/mask : <input type="text" value="255.255.255.0"/>
	Max Access : <input checked="" type="radio"/> Read only <input type="radio"/> Read/Write

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-38. SNMP community-edit

Community	Click “Public” as the community string in SNMP protocol. Click “Private” as the community string in SNMP protocol.
Host/mask	Assign a value of subnet mask for host IP address.
Max Access	Select the authority as “Read only” or “Read/Write” . Read only means user only can monitor managed devices. Read/Write means user can control managed devices including change the values of variable stored within managed devices.

Click **Apply** to finish this setting.

Click **Delete** to remove this entry. The page is shown as Figure 6-39.




Figure 6-39. SNMP community-delete

Click **Delete All** to remove all entries in the table. The page is shown as Figure 6-40.




Figure 6-40. SNMP community-delete all

6.11.2 SNMP Traps

In managed network by SNMP protocol, agent will send a specific packet as an attention for administrator; it is called “**Trap**”. Trap is the only PDU sent by an agent on its own initiative. It is used to notify the management station of an unusual event that may demand further attention (like a link down).

Click **SNMP Traps** option, the page is shown as Figure 6-41.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 8:08:16 P.M.

EMS - SNMP Traps

#	Trap Server	Trap Community	Trap server port
1	<input checked="" type="radio"/>		
2	<input type="radio"/>		
3	<input type="radio"/>		
4	<input type="radio"/>		
5	<input type="radio"/>		
6	<input type="radio"/>		
7	<input type="radio"/>		
8	<input type="radio"/>		
9	<input type="radio"/>		
10	<input type="radio"/>		

1

Edit Delete Delete All

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-41. SNMP traps configuration

Click **Edit** button, the page is shown as Figure 6-42.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 8:11:45 P.M.

EMS - SNMP Traps - Edit

1	Trap server :	192.168.1.100
	Trap community :	public
	Trap server port :	2048

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 6-42. SNMP Traps-Edit

Trap server	Assign an IP address of trap server.
Trap community	Assign a community string for Trap packet using.
Trap server port	Assign a port number for Trap server using.

Click **Delete** option to remove this entry.

Click **Delete All** option to remove all the entries in the table.

CHAPTER 7

Firewall Setup

This chapter shows how to configure your router's firewall feature. The firewall controls which packets to allow or deny into or out of the router.

This chapter is divided into the following sections.

- Section 7.1: Introduction
- Section 7.2: An Overview of the Firewall Setup
- Section 7.3: IP Filter Setup
- Section 7.4: Denial of Service Attacks Setup
- Section 7.5: URL Filter Setup

7.1 Introduction

The **Firewall Setup** in the Vigor 3300 mainly consists of packet filtering, Denial of Service (DoS) and URL (Universal Resource Locator) content filtering facilities. These firewall filters help to protect your local network against attack from outsiders. A firewall also provides a way of restricting users on the local network from accessing inappropriate Internet content and can filter out specific packets, which may trigger an unexpected outgoing connection such as a Trojan.

Firewall Setup

There is group, filter definition on the firewall Web page as follows. A group contains filter rules, and a filter is a member of a particular group. Before IP filter rules are set, a group should be created to arrange and maintain filter rules. One group should be selected as the starting group to enable the firewall function.

In the next group setting, the order of groups can be arranged. A filter rule can also link to another group for advanced properties. An example is shown in Figure 7-1.




Figure 7-1. Concept of filter rules group

7.2 An Overview of the Firewall Setup

The following sections will explain how to configure the **Firewall**. User can select the **Firewall** option in the menu to find the **General Setup**, **IP Filter**, **DoS** and **URL Filter** options.

The **DoS** facility can detect and mitigate the DoS attacks. The **URL Filter** can block inappropriate websites for SME. The setting is shown in Figure 7-2.




Figure 7-2. The firewall option

7.3 IP Filter Setup

First, you should create at least one Group in the **IP Filter > Group Table**. Then you can enable the **Data Filter** and select a **Start Filter Group** in **General Setup**. The following sections explain **IP Filter** functions with details.

7.3.1 General Setup

Click the **General Setup** option to bring up the following Web page as shown in Figure 7-3.

The screenshot shows the 'Vigor3300 series MultiService Security' web interface. The top navigation bar includes 'Quick Setup', 'System', 'Network', 'Advance', 'Firewall', 'QoS', 'VPN', and 'VoIP'. The 'Firewall' tab is selected, and the 'General Setup' sub-tab is active. The 'Data Filter' section has two radio buttons: 'Disable' (selected) and 'Enable'. Below it, the 'Start Filter Group' dropdown menu is set to 'G1'. The 'Apply' and 'Cancel' buttons are located at the bottom right of the form. The footer of the page reads: 'DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 7-3. General configuration

Data Filter	“Disable” or “Enable” the firewall function. This firewall can only be enabled if at least one filter group exists. The default is Disable
Start Filter Group	Select the first filter group to begin filtering mechanism. The group in this list must exist and had been pre-configured.

7.3.2 Group Table Setup

Click the **Group Table** option to bring up the following Web page and shown in Figure 7-4.



Figure 7-4. Group table configuration

Click **Delete**¹ to remove a group from the IP Filter table configuration.

Click **Add** to add a new Group. The Web page is shown in Figure 7-5.

¹ If this entry is assigned as the started filter group already, it cannot be deleted unless the Data Filter function is disabled in General Setup page in Figure 7-7.

Firewall Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP

Firewall - IP Filter Table

Group Name :

Next Group Name :

Comment :

DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution.

Figure 7-5. Add IP filter group

Group Name	The name of the group.
Next Group Name	The next group to filter packets.
Comment	A comment or description for the group.

Fill out the **Group Name**, **Next Group Name** and **Comment** fields. Click **Apply** when you are finished to apply the settings, or click **Cancel** to go back without saving the settings. Users should change any setting on the same screen by clicking **Edit**² to modify an IP Filter table configuration as Figure 7-6.

² In Edit mode, the Group Name field cannot be modified.

Firewall Setup

The screenshot shows the 'Firewall - IP Filter Table' configuration page. At the top, there is a header with 'Vigor3300 series MultiService Security' and 'VIGOROUS BROADBAND ACCESS'. Below the header is a navigation bar with tabs: Quick Setup, System, Network, Advance, Firewall, QoS, VPN, and VoIP. The 'Firewall' tab is selected. The main content area is titled 'Firewall - IP Filter Table'. It contains three input fields: 'Group Name' with the value 'G1', 'Next Group Name' with a dropdown menu showing 'none', and 'Comment' with the value 'group1'. There are 'Apply' and 'Cancel' buttons at the bottom right. At the bottom of the page, there is a footer with the text 'DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 7-6. Edit IP filter table entry

Click **Apply** to apply the settings.

The screenshot shows the 'Firewall - IP Filter - Group Table' configuration page. At the top, there is a header with 'Vigor3300 series MultiService Security' and 'VIGOROUS BROADBAND ACCESS'. Below the header is a navigation bar with tabs: Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The 'Firewall' tab is selected. The main content area is titled 'Firewall - IP Filter - Group Table'. It contains a table with the following columns: Index, Group Name, Next Group, and Comment. The table has one row with Index '1', Group Name 'G1', Next Group 'none', and Comment 'first group'. There are 'Add', 'Edit', and 'Delete' buttons at the bottom right. A confirmation dialog box is open in the foreground, titled 'Microsoft Internet Explorer', with the text 'Are you sure of deleting this group?' and 'OK' and 'Cancel' buttons. At the bottom of the page, there is a footer with the text '© 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 7-7. Delete IP filter table

7.3.3 Add Filter Rule

Click **Add Rule** icon under **Firewall->IP Filter Table** to add a new rule as following Web page in Figure 7-8³.

The screenshot shows the 'Vigor3300 series MultiService Security' web interface. The top navigation bar includes 'Quick Setup', 'System', 'Network', 'Advanced', 'Firewall', 'QoS', 'VPN', and 'VoIP'. The 'Firewall' tab is selected, and the page title is 'Firewall - IP Filter - Add Filter Rule'. The configuration is divided into two main sections: 'Filter Condition' and 'Action'.

Filter Condition:

- ☒ Active
- Source:
 - IP: 192.168.1.77
 - Subnet Mask: 255.255.255.0
 - Port: between 100 - 200
- Destination:
 - IP: 10.1.1.77
 - Subnet Mask: 255.255.255.0
 - Port: between 100 - 200
- Group Name: Group1
- Protocol: TCP
- Direction: In
- Fragment: do not care

Action:

- Block or Pass: Block immediately
- Next Group Name: none

Buttons: Apply, Cancel

Figure 7-8. IP filter configuration

³ Don't forget to click the Active checkbox to activate this rule.

Firewall Setup

<i>Source IP</i>	It is the source IP address. Placing the symbol “!” before a particular IP address will prevent this rule from being applied to that IP address. It is equal to the logical NOT operator.
<i>Subnet Mask</i>	It is the subnet mask for the source IP.
<i>Source Port</i>	It is the port for the source IP
<i>Destination IP</i>	It is the destination IP address for this filter rule. Placing the symbol “!” before a particular IP address will prevent this rule from being applied to that IP address. It is equal to the logical NOT operator.
<i>Destination Mask</i>	It is the subnet mask for the destination IP.
<i>Destination Port</i>	It is the port for the destination IP.
<i>Group Name</i>	It is the filter group for the current rule.
<i>Direction</i>	The direction of packet flow IN is for incoming packets. OUT is for outgoing packets, and Any is for both directions.
<i>Protocol</i>	It is the protocol(s) for this filter rule.
<i>Fragments</i>	<p>It is the response to fragmented packets. There are three options as below.</p> <ul style="list-style-type: none">● Do not care: Specifies no fragment options.● Unfragment: Applies the rule to unfragment packets.● Fragmented: Applies the rule to fragmented packets.

Firewall Setup

Block or Pass	The action to be taken when packets match the rule. There are four options: <ul style="list-style-type: none">● Block immediately: Block the packet immediately.● Pass immediately: Pass the packet immediately.● Block if no further match: means to locks the packet if no further rules are matched.● Pass if no further match: means to passes the packet if no further rules are matched.
Next Group Name	It indicates the next filter group. If the option Block if no further match or Pass if no further match of Block or Pass parameter is selected, the unmatched packets will be compared with rules in Next Group . The option None must be chosen while Block or Pass is selected as Block or Pass .

(Operator)

The operator column specifies the port number settings. If the **Start Port** column is empty, the **Start Port** and the **End Port** column will be ignored. The filter rule will filter out any port number.

=: If the **End Port** column is empty, the filter rule will set the port number to be the value of the **Start Port** column. Otherwise, the port number ranges from the **Start Port** to the **End Port** including the **Start Port** and the **End Port**.

!=: If the **End Port** column is empty, the port number is not equal to the value of the **Start Port** column. Otherwise, this port number is not between the **Start Port** and the **End Port** including the **Start Port** and **End Port**.

>: Specifies the port number is larger than or equal to the **Start Port**.

<: Specifies the port number is less than or equal to the **Start Port**.

7.4 Denial of Service Attacks Setup

The DoS function helps to detect and mitigates DoS attacks. These include flooding-type attacks and vulnerability attacks. Flooding-type attacks attempt to use up all your system's resources while vulnerability attacks try to paralyze the system by offending the vulnerabilities of the protocol or operation system. Click the **DoS** option under the **Firewall** menu in Figure 7-8 and to set up the **DoS** function in Figure 7-9.




Figure 7-8. The DoS option

Firewall Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP

Firewall - DoS

DoS Defense : ☐ Disable ☒ Enable

<input checked="" type="checkbox"/> Enable SYN flood defense :	Threshold: <input type="text" value="300"/> Packets/sec	Timeout: <input type="text" value="10"/> sec
<input checked="" type="checkbox"/> Enable UDP flood defense :	Threshold: <input type="text" value="300"/> Packets/sec	Timeout: <input type="text" value="10"/> sec
<input checked="" type="checkbox"/> Enable ICMP flood defense :	Threshold: <input type="text" value="300"/> Packets/sec	Timeout: <input type="text" value="10"/> sec
<input checked="" type="checkbox"/> Enable Port Scan detection :	Threshold: <input type="text" value="300"/> Packets/sec	

☐ Block IP options
☐ Block Land
☐ Block Smurf
☐ Block trace route
☐ Block SYN fragment
☐ Block Fraggle Attack

☐ Block TCP flag scan
☐ Block Tear Drop
☐ Block Ping of Death
☐ Block ICMP fragment
☐ Block Unknown Protocol

Apply Cancel

DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution.

Figure 7-9. DoS configuration

The DoS Defense Engine inspects each incoming packet against the attack signature database. Any packet that may paralyze the host in the security zone is blocked. The DoS Defense Engine also monitors traffic behavior. Any anomalous situation violating the DoS configuration is reported and the corresponding defense function is executed to mitigate the attack.

Firewall Setup

The following section will explain the DoS Defense Setup in more detail. It is a sub-functionality of the IP filter. There are 15 kinds of defense functions for the DoS Defense Setup. A brief description for each function is shown below.

<i>DoS Defense</i>	Enables or Disables the DoS Defense function. Default value is Disable .
<i>Enable SYN Flood Defense</i>	Activates the SYN flood defense function. If the amount of TCP SYN packets from the Internet exceeds the user-defined threshold value, the router will be forced to randomly discard the subsequent TCP SYN packets within the user-defined timeout period. The default setting for threshold and timeout are 300 packets per second and 10 seconds, respectively.
<i>Enable UDP Flood Defense</i>	Activates the UDP flood defense function. If the amount of UDP packets from the Internet exceeds the user-defined threshold value, the router will be forced to randomly discard the subsequent UDP packets within the user-defined timeout period. The default setting for threshold and timeout are 300 packets per second and 10 seconds, respectively.
<i>Enable ICMP Flood Defense</i>	Activates the ICMP flood defense function. If the amount of ICMP echo requests from the Internet exceeds the user-defined threshold value, the router will discard the subsequent echo requests within the user-defined timeout period. The default setting for threshold and timeout are 300 packets per second and 10 seconds, respectively.

Firewall Setup

<i>Enable Port Scan Detection</i>	Activates the Port Scan detection function. Port scan sends packets with different port numbers to find available services, which respond. The router will identify it and report a warning message if the port scanning rate in packets per second exceeds the user-defined threshold value. The default threshold is 300 pps (packets per second).
<i>Enable Block IP Options</i>	Activates the Block IP options function. The router will ignore any IP packets with IP option field appearing in the datagram header.
<i>Enable Block Land</i>	Activates the Block Land function. A Land attack occurs when an attacker sends spoofed SYN packets with identical source address, destination addresses and port number as those of the victim.
<i>Enable Block Smurf</i>	Activates the Block Smurf function. The router will reject any ICMP echo request destined for the broadcast address.
<i>Enable Block Trace Route</i>	Activates the Block trace route function. The router will not forward any trace route packets.
<i>Enable Block SYN Fragment</i>	Activates the Block SYN fragment function. Any packets having the SYN flag and fragmented bit sets will be dropped.
<i>Enable Block Fraggle Attack</i>	Activates the Block fraggle Attack function. Any broadcast UDP packets received from the Internet are blocked.
<i>Enable TCP Flag Scan</i>	Activates the Block TCP flag scan function. Any TCP packet with an anomalous flag setting is dropped. These scanning activities include no flag scan , FIN without ACK scan , SYN FIN scan , Xmas scan and full Xmas scan .

Firewall Setup

<i>Enable Tear Drop</i>	Activates the Block Tear Drop function. This attack involves the perpetrator sending overlapping packets to the target hosts so that target host will hang once they re-construct the packets. The routers will block any packets resembling this attacking activity.
<i>Enable Ping of Death</i>	Activates the Block Ping of Death function. Many machines may crash when receiving an ICMP datagram that exceeds the maximum length. The router will block any fragmented ICMP packets with a length greater than 1024 octets.
<i>Enable Block ICMP Fragment</i>	Activates the Block ICMP fragment function. Any ICMP packets with fragmented bit sets are dropped.
<i>Enable Block Unknown Protocol</i>	Activates the Block Unknown Protocol function. The router will block any packets with unknown protocol types.

Click **Apply** to apply the settings.

7.5 URL Filter Setup

7.5.1 Introduction

The Internet contains a wide range of offenses or illegal materials. Unlike traditional media, the Internet does not have any obvious tools to segregate materials based on URL strings or content. URL content filtering systems are seen as tools that would provide the cyberspace equivalent of the physical separations that are used to limit access to particular materials. By rating a site as objectionable, and refusing to display it on user's browser, URL content filter can prevent employee on SME from accessing inappropriate Internet resources.

Instead of traditional firewall inspects packets based on the fields of TCP/IP headers, the URL content filter checks the URL strings or the payload of TCP/IP packets.

7.5.2 An Overview of URL Content Filtering




Figure 7-10. URL filtering example

The URL content filter in the series of broadband security routers inspects every URL string in the HTTP request initiated inside against the keyword list. If the entire or part of the URL string (for instance, <http://www.draytek.com>, as shown as Figure 7-11) matches any activated keyword, the first and the following associate HTTP request will be blocked. The system will discard any request, which tries to retrieve the malicious code.

Notice that you must clear your browser cache first so that the URL content filter operates properly on a Web page that you visited before.

7.5.3 URL Content Filter Configuration

The following sections describe the Web configuration for setting up the URL content filter, including specific configuration information and limitations.

The URL content filter consists of the following functions: **URL Access Control**, **Block Web access by IP address**, **Restrict Web Feature**, **Excepting Subnets**, and **Filter Schedule**. The **URL Access Control** controls Web site access by inspecting the URL string against user-defined keywords. The **Restrict Web Feature** control blocks malicious codes hidden in Web pages, such as Java Applet, Active X, Cookies, Proxy, compressed files, and executable files. It is also able to block all downloads of multimedia files from Web pages in order to control the bandwidth usage.

The **Block Web access by IP address** function is used to avoid inappropriate Web sites that can be accessed directly using the IP address in the URL locator. The **Excepting Subnets** function allows the administrator to specify a group of hosts that are free from the URL Access Control. This group of hosts can be defined as a set of IP addresses or subnets. Finally, the **Filter Schedule** function controls what times the URL content filter should be active.

Firewall Setup

Click the **URL Filter** option in the **Firewall** menu in Figure 7-11 and to configure the **URL Filter** in Figure 7-12.




Figure 7-11. The URL filter option

Firewall Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 11:44:48 A.M.

Firewall - URL Filter

☐ Disable ☒ Enable

URL Access Control SurfControl Restrict Web Feature Filter Schedule

Access Control by Keyword

Keyword: Add Edit Delete

Keyword List:

Block Direct IP Web Access

☐ Block Direct IP Web Access

Exception List

☒ Enable Exception List

IP Address: Subnet Mask: Add Edit Delete

Exception List:

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 7-12. URL filter on URL access control

Enable/Disable	“Disable” or “Enable” URL Filter function.
-----------------------	---

7.5.3.1 URL Access Control Setup

<i>Access Control by Keyword</i>	
<i>Keyword</i>	The keyword(s) used to filter URLs. Keywords can be partial words or complete URLs. The router will reject any Website which whole or partial URL matches any keywords.
<i>Keyword List</i>	The list of keywords.
<i>Block Direct IP Web Access</i>	
<i>Block Direct IP Web Access</i>	Deny any Web surfing activity that directly uses an IP address.
<i>Exception List</i>	
<i>Enable Excepting List</i>	Click it to allow specified IP addresses or subnets to be passed through.
<i>IP Address</i>	The allowed IP address.
<i>Subnet Mask</i>	The allowed subnet mask of IP address.
<i>Exception List</i>	The list of IP addresses where content filter rules are not applied.

Firewall Setup

7.5.3.2 SurfControl Setup

Click the **SurfControl** page as Figure 7-13 to set up this function.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 11:51:29 A.M.


Firewall - URL Filter

☐ Disable ☒ Enable

URL Access Control **SurfControl** Restrict Web Feature Filter Schedule

Access Control by Category

CPA Server: ☐ Disable ☒ Enable

Select a CPA Server: [Activate Free Trial and Purchase Subscription](#) [Test a site to verify whether it is categorized](#) 

Permitted Categories List:

Forbidden Categories List:

*Categories are downloaded from the Surfcontrol Server.

URL: Option:

Exception URL List:

Examples of URL:
"www.abc.org" all items under this host and the host itself will be considered.
"www.abc.org/direct" all items under this host's particular directory, excluding the directory itself, will be considered.
"www.abc.org/page.htm" only this particular item (page or file) will be considered.

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 7-13. URL filter on SurfControl

Firewall Setup

<i>Access Control by Category</i>	
<i>CPA Server</i>	Enable or Disable URL Access Control.
<i>Select a CPA Server</i>	The domain name is used to as a CPA server. The name should be filled when enable CPA Server, otherwise it will impact performance.
<i>Permitted Categories List</i>	The permitted categories are from the selected CPA server.
<i>Forbidden Categories List</i>	The forbidden categories are from the selected CPA server.
<i>Category Exception List</i>	
<i>URL</i>	The URL domain name.
<i>Option</i>	Allow or Deny the selected URL.
<i>Exception URL List</i>	The list of filtered URLs.

Example - If you want to filter any website whose URL string contains “sex”, “gun”, or “drug”, you should add these words into the keyword frames. Thus, the system will automatically deny any Web surfing with the URL string containing any one of the keywords listed. If the user tries to access [www.backdoor.net/images/sex /p_386.html](http://www.backdoor.net/images/sex/p_386.html), the router will deny the connection because this website is prohibited. However, the user is still able to access the website www.backdoor.net/firewall/forum/d_123.html. Further, the URL content filtering facility also allows you to specify either a complete URL string (e.g., “www.whitehouse.com” and “www.hotmail.com”) or a partial URL string (e.g., “yahoo.com”) in the blocking keyword list. Accordingly, the router will identify the forbidden URL and deny the associated connections.

Firewall Setup

7.5.3.3 Restrict Web Feature Setup

Malicious code may be embedded in some executable objects, such as ActiveX, Java Applet, compressed files, executable files, Proxy, and Multimedia. For example, an ActiveX object with malicious code may gain unlimited access to the system. Click the **Restrict Web Feature** tab (Figure 7-14) to set up this function.



Figure 7-14. URL filter for restrict web feature

Firewall Setup

<i>Java</i>	Activates the Block Java object function. The router will discard Java objects from the Internet.
<i>ActiveX</i>	Activates the Block ActiveX object function. The router will discard ActiveX object from the Internet.
<i>Compressed Files</i>	Activates the Block Compressed file function to prevent downloading of any compressed file. These following types of compressed files are blocked by the router. .zip .rar .arj .ace .cab .sit
<i>Execution Files</i>	Activates the Block Executable file function to prevent downloading of any executable file. The following types of executable files are blocked by the router. .exe .com .scr .pif .bas .bat .inf .reg
<i>Cookie</i>	Activates the Block Cookie function. Cookies are used by many websites to create “stateful” sessions for tracking Internet users, which would violate the users’ privacy. The router will filter out all cookies-related transmissions.
<i>Proxy</i>	Activates the Block Proxy function. The router will filter out all proxy-related transmissions.
<i>Multimedia Files</i>	Activates the Block Multimedia function. The router will filter out multimedia from any website.

Firewall Setup

7.5.3.4 Filter Schedule Setup

The Filter Schedule specifies what times the URL content filtering facility should be active in Figure 7-15.

The screenshot shows the 'Vigor3300 series MultiService Security' web interface. The top navigation bar includes 'Quick Setup', 'System', 'Network', 'Advanced', 'Firewall', 'QoS', 'VPN', and 'VoIP'. The 'Firewall' tab is active, and the 'URL Filter' sub-tab is selected. Under 'Firewall - URL Filter', there are radio buttons for 'Disable' and 'Enable'. Below this, there are four tabs: 'URL Access Control', 'SurfControl', 'Restrict Web Feature', and 'Filter Schedule' (which is highlighted). In the 'Filter Schedule' section, the 'Block only at' option is selected. The time range is set to '8 : 00' To '18 : 00'. The 'Day of Week' section shows checkboxes for 'All Days', 'Sun', 'Mon', 'Tue', 'Wed', 'Thu', 'Fri', and 'Sat'. The 'Mon', 'Tue', 'Wed', 'Thu', and 'Fri' checkboxes are checked. At the bottom right, there are 'Apply' and 'Cancel' buttons. A footer note at the bottom of the page reads: 'DrayTek Corp., © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.'

Figure 7-15. URL filter for filter schedule

<i>Always Block</i>	The URL content filtering facility is always active.
<i>Block Only at</i>	The URL content filtering facility is active during the specified times from <i>H1:M1</i> to <i>H2:M2</i> in one day, where <i>H1</i> and <i>H2</i> indicate the hours and <i>M1</i> and <i>M2</i> represent the minutes.
<i>Days of Week</i>	The URL content filtering facility is active during the specified days of the week. The default value is 8:00 to 18:00 from Monday to Friday.

7.5.4 Warning Message

When an HTTP request is denied, an alert page will appear in your browser, as shown in Figure 7-16.




Figure 7-16. Warning message

CHAPTER 8

VPN (Virtual Private Network) and Remote Access Setup

This chapter shows how to setup the configuration of VPN and Remote Access to let users create a virtual private network for security in the Internet.

This chapter is divided into the following sections.

- Section 8.1: Introduction
- Section 8.2: IPSec Group Setup
- Section 8.3: PPTP Group Setup

8.1 Introduction

A Virtual Private Network (VPN) is an extension of a private network that encompasses links across shared or public networks like the Intranet. A VPN enables you to send data between two hosts across a shared or public network in a manner that emulates the properties of a point-to-point private link.

There are two types of VPN connections: remote dial-in access and LAN-to-LAN connection. The “Remote dial-In Access” facility allows a remote access node, a NAT router or a single computer to dial into a VPN router through the Internet to access the network resources of the remote network. The “LAN-to-LAN Access” facility connects two independent LANs for mutual sharing of network resources. For example, the head office network can access the branch office network, and vice versa.

The VPN technology implemented in the Vigor3300 series of broadband security routers supports Internet-industry standards to provide customers with interoperable VPN solutions, such as X.509 and DHCP over Internet Protocol Security (IPSec). This VPN feature is only supported for Vigor 3300, Vigor3300V routers. IPSec is the security architecture for IP networks. IPSec provides security services at the IP layer by enabling a system to select required security protocols. It determines the algorithms to use for the services, and puts in place any cryptographic keys required to provide the requested services. IPSec can be used to protect one or more "paths" between a pair of hosts, between a pair of security gateways, or between a security gateway and a host.

The IPSec services can provide access control, connectionless integrity, data origin authentication, rejection of replayed packets that is a form of partial sequence integrity, and confidentiality by encryption. These objectives are met through the use of two traffic security protocols, the Authentication Header (AH) and the Encapsulating Security Payload (ESP), and through the use of cryptographic key management procedures and protocols.

The Vigor3300 series supports ESP Tunnel mode with IKE for key management. Internet Key Exchange (IKE) Protocol, a key protocol in the IPSec architecture, is a hybrid protocol using part of Oakley and part of SKEME in conjunction with ISAKMP to obtain authenticated keying material for use with ISAKMP, and for other security associations such as AH and ESP for the IPsec DOI.

VPN and Remote Access Setup

Click the VPN option to configure the VPN Setup in Figure 8-1.

The screenshot displays the web management interface for a Vigor3300 series MultiService Security device. The top navigation bar includes tabs for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The 'VPN' tab is currently selected. Below the navigation bar, there is a 'System - Status' section with a 'Refresh Option' dropdown set to 'No Refresh'. A sub-menu is open under the 'VPN' tab, showing options for IPSec and PPTP. The main content area features a 'Basic Status' tab, which is active, displaying system information such as Model (Vigor3300V), Hardware Version (1.0), Firmware Version (2.5.6 RC3), Build Date&Time (Tue Sep 13 17:42:00 CST 2005), System Uptime (0 days 2 hours 27 minutes 7 seconds), CPU Usage (8.4668%), Memory Usage (57.8303%), and Current System Time (Fri Sep 23 21:19:55 2005). The footer of the interface contains the copyright notice: DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-1. The VPN option

8.2 IPSec Group Setup

8.2.1 Policy Table Setup

To create a VPN IPSec policy, click the **Policy Table** option under the **IPSec** menu in Figure 8-2 and bring up the Policy Table Setup in Figure 8-3.




Figure 8-2. The VPN policy table option

VPN and Remote Access Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup
System
Network
Advanced
Firewall
QoS
VPN
VoIP
1:25:09 P.M.

VPN - IPSec - Policy Table

#	Connection Name	Local Subnet	Remote Gateway	Remote Subnet	Admin Status	Operational Status	Action
1	A	10.1.1.1/24	0.0.0.0	20.1.1.1/24	enable	down	Initiate
2							
3							
4							
5							
6							
7							
8							
9							
10							

1

Refresh
Edit
Delete
Delete All

Figure 8-3. VPN policy table setup

There are four options:

<i>Refresh</i>	Refresh the page information.
<i>Edit</i>	Configure an entry.
<i>Delete</i>	Delete a designated entry.
<i>Delete All</i>	Delete all entries in the table.

8.2.2.1 Default Setup

Select an entry and click **Edit** to create a new IPSec Tunnel in Figure 8-4.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 1:33:55 P.M.

VPN - IPSec Tunnel

Default Advanced

Basic

Name : A

Authentication : Preshared Key

Preshared Key :

Security Protocol : ESP

Admin Status : Enable

Local Gateway

WAN Interface : WAN1

Local Certificate :

Security Gateway : default

Network IP / Subnet Mask : 10.1.1.1 / 24

Next hop : default

Remote Gateway

Remote ID :

DHCP-over-IPSec : OFF

Security Gateway : 0.0.0.0

Network IP / Subnet Mask : 20.1.1.1 / 24

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-4. IPSec tunnel configuration

Basic	
Name	The name for VPN connection (ex. "VPN1"). The maximum length of name is 20 characters including spaces.
Authentication	The authentication to be used by PreShared Key or RSA Signature.

VPN and Remote Access Setup

<i>PreShared Key</i>	The shared key for peer identification. The maximum length is 40 characters, including spaces.
<i>Security Protocol</i>	AH: Specify the IPSec protocol for the Authentication Header protocol. The data will be authenticated, but not be encrypted. ESP: Specify the IPSec protocol for the Encapsulating Security Payload protocol. The data will be encrypted and authenticated.
<i>Admin Status</i>	The administrative status. Enable the policy to wait for a peer to initiate the IKE negotiation. Disable the policy to deactivate the VPN connection. The Always-on is recommended and automatically activates a VPN connection indefinitely.
<i>Local Gateway</i>	
<i>WAN Interface</i>	The WAN interface to be used.
<i>Local Certificate</i>	The local certificate to be used for authentication if the “RSA Signature” option is selected in the “Authentication” field. These options are from the user certificate file.
<i>Security Gateway</i>	The IP address of the local gateway's public-network interface. The keyword “default” can be used to represent the IP Address of the selected “WAN Interface”.
<i>Network IP / Subnet Mask</i>	The subnet behind the local gateway.
<i>Next Hop</i>	The IP address of the next hop. The keyword “default” can be used to represent the gateway IP address of the selected “WAN Interface”.
<i>Remote Gateway</i>	
<i>Remote ID</i>	The identification number for the remote gateway.
<i>DHCP-over-IPSEC</i>	Turns this function ON or OFF .

VPN and Remote Access Setup

Security Gateway	The IP address of the remote client/gateway. This field is mandatory. The setting for 0.0.0.0 is used for the road-warrior with a dynamic IP address.
Network IP / Subnet Mask	The subnet behind the remote gateway. If the remote gateway IP address is 0.0.0.0, this field can be omitted, but you can specify it as 0.0.0.0/32 for clarity.

8.2.2.2 Advance Setup

Click the **Advanced** tab to see the Advanced Setup page in Figure 8-5.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network **Advanced** Firewall QoS VPN VoIP 1:51:48 P.M.

VPN - IPSec Tunnel

Default **Advanced**

IKE Phase1(main mode)

Key lifetime : 480 minutes

Proposal : des-md5-mdp768 des-sha-mdp768 3des-md5-mdp768 3des-sha-mdp1024

IKE Phase2(quick mode)

Key lifetime : 60 minutes

Proposal : des-md5 des-sha1 3des-md5 3des-sha1

☐ PFS (Perfect Forward Secrecy)

Dead Peer Detection

Status : ☒ Disable ☐ Enable

Delay : 30 seconds

Timeout : 120 seconds

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-5. VPN advanced configuration

<i>IKE Phase1 Group (Main Mode)</i>	
<i>Key Lifetime</i>	The rekey-renegotiated period of the IKE Phase1 keying channel of a connection. The acceptable range is from 5 to 480 minutes (8 hours).
<i>Proposal</i>	The proposed encryption and/or authentication algorithms for IKE Phase1 negotiation. There are 3 options: <i>Encryption algorithms</i> - DES/3DES/AES <i>Authentication algorithms</i> - MD5/SHA1 <i>DH Group</i> - MODP768/MODP1024/MODP1536.
<i>IKE Phase 2(Quick Mode)</i>	
<i>Key Lifetime</i>	The rekey-renegotiated period of the IKE Phase2 keying channel. The acceptable range is from 5 to 1440 minutes (24 hours).
<i>Proposal</i>	The proposed encryption and/or authentication algorithms for IKE Phase2 negotiations. There are 2 options. <i>Encryption algorithms</i> –NULL/DES/3DES/AES. <i>Authentication algorithms</i> - MD5/SHA1
<i>PFS</i>	Enables the PFS (Perfect Forward Secrecy) function. A new Diffie-Hellman Key Exchange is included every time an encryption and/or authentication key are computed on PFS.
<i>Dead Peer Detection</i>	
<i>Status</i>	Enables or Disables the function.
<i>Delay</i>	The keep-alive timer. A Hello message will be emitted periodically when a tunnel is idle. Use the value 0 to disable this function. The recommended value is 30 seconds if enabled.

VPN and Remote Access Setup

Timeout	The timeout timer. The peer will be declared dead once no acknowledge message is received after timeout value. Use the value 0 to disable this function. The recommended value is 120 seconds if enabled.
----------------	---

Click **Apply** to apply the IPSec policy setting and add a new record into the policy table in Figure 8-6.

The screenshot shows the web interface of a Vigor3300 series MultiService Security device. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The main content area is titled "VPN - IPSec - Policy Table" and displays a table with the following data:

#	Connection Name	Local Subnet	Remote Gateway	Remote Subnet	Admin Status	Operational Status	Action
1	A	10.1.1.1/24	0.0.0.0	20.1.1.1/24	enable	down	Initiate
2							
3							
4							
5							
6							
7							
8							
9							
10							

At the bottom of the table, there is a "Refresh" button, an "Edit" button, a "Delete" button, and a "Delete All" button. The page footer indicates "DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution."

Figure 8-6. VPN policy table list

Significant fields will be summarized in the IPSec Table. **Operational Status** reflects the current status of the tunnel. “UP” means the IPSec tunnel has been established. “DOWN” means no tunnel existing, or termination status of the tunnel.

If user expects the local gateway to act as the IKE initiator, i.e., emit the first IKE main mode message; user can click the hyperlink Initiate to start the IKE negotiation or set admin status to be always on to automatically restart IKE negotiation. During the negotiation, you can press Refresh to show the latest status of all policies.

8.2.2 Log

At any time, you can click **VPN > Log** to monitor the VPN tunnel status (Figure 8-7). The log is helpful for solving some setting problems. The system will keep the 100 most recent messages. Click **Clear** to clear the log.



The screenshot shows the web interface of a Vigor3300 series MultiService Security device. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The current page is titled "VPN - IPSec - Log". It features a table with the following data:

#	Date/Time	Description
1	21:55:49 09/23	connection {1_A} is added
2	21:55:43 09/23	connection {1_A} is deleted
3	18:56:05 09/23	connection {1_A} is added

Buttons for "Refresh" and "Clear" are located at the top right and bottom right of the log table.

Figure 8-7. VPN log information

8.2.3 Trust CA Setup

Click the **VPN->IPSec->Trust CA** option to set up the CA configuration in Figure 8-8.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 3:14:03 P.M.

VPN - IPSec - Trust CA

#	Name	Issuer
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

1

Upload Delete View

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-8. VPN IPSec trust CA configuration

Select an entry, and then click the **Upload** option (Figure 8-9).

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 3:28:25 P.M.

VPN - IPSec - Trust CA # 1 - Upload

Upload CA Certificate

Upload File C:\cacert.pem Browse...

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-9. Upload VPN IPSec trust CA

8.2.4 User Certificate

Click the User Certificate option to see the User Certificate page in Figure 8-10.




Figure 8-10. VPN IPsec user certificate

There are five options:

Generate	Generate a new entry for user certification.
Download	Download a certification file generated from router to be stored in local host.
Import	Import a certificated file from server.
Delete	Delete an assigned entry.
View	Show configuration of the assigned entry.

8.2.4.1 Generate Setup

Click **Generate** to bring up the following web page in Figure 8-11.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 1:33:03 P.M.

VPN - IPsec - User Certificate # 1 - Generate

Generate Certificate Signing Request

Certification Name: 3300CA_0804

ID Type: Domain Name

ID Value:

User Certificate Information

Organization Unit: RD3

Organization: Draytek

Locality(City): Houko

State/Province: Hsin-Chu

Common Name: abc

Country: Taiwan

e-mail: abc@draytek.com.tw

Key Size: 1024 Bits

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-11. Generate VPN IPsec user certificate

Generate Certificate Signing Request	
Certification Name	The name of the certification entry.
ID Type	<p>The ID type for this entry.</p> <p>There are three types:</p> <ul style="list-style-type: none"> ● Domain Name: Certificated by domain name. ● IP: Certificated by IP address. ● Email: Certificated by email address.
ID Value	The ID value for this entry.

<i>User Certification Information</i>	
<i>Organization Unit</i>	The unit value of this organization.
<i>Organization</i>	The value of this organization.
<i>Locality (City)</i>	The local city name of this entry.
<i>State/Province</i>	The state name of this entry.
<i>Common Name</i>	The common name for this entry.
<i>Country</i>	The country name of this entry.
<i>E-mail</i>	The email address of this entry.
<i>Key Size</i>	<p>The key size for this entry.</p> <p>There are 3 options:</p> <ul style="list-style-type: none"> ● 1024 Bits ● 1536 Bits ● 2048 Bits

8.2.4.2 Download Setup

This function exports a certification file generated in the router to a local host. This file must be removed to a certification server for certification (Figure 8-12).

VPN and Remote Access Setup




Figure 8-12. Download VPN IPsec user certificate

DrayTek

8.2.4.3 Import Setup

Click **Import** to bring up the following web page in Figure 8-13. Select a certified file from a local host and click **Apply** to import the user certificate.

Figure 8-13. Import VPN IPsec user certificate

8.2.4.4 Delete Setup

Click **Delete** to delete a user certificate in Figure 8-14. Any User Certificate can be deleted from this table.

#	Status	Name	Issuer
1	Request Generated	3300CA	
2	Empty		
3	Empty		
4	Empty		
5	Empty		
6	Empty		
7	Empty		
8	Empty		
9	Empty		
10	Empty		

Figure 8-14. Delete VPN IPsec user certificate

8.2.4.5 View

Click **View** to view the certification information in Figure 8-15.



Figure 8-15. View VPN IPSec user certificate

8.2.5 Status

The **Status** page is shown in Figure 8-16.




Figure. 8-16 VPN connection status

8.3 PPTP Group Setup

8.3.1 General Setup

The Vigor3300 series supports PPTP configuration through the VPN function in Figure 8-17.




Figure 8-17. The VPN PPTP option

8.3.1.1 General Setup

Click **VPN -> PPTP->General Setup** to bring up the following web page in Figure 8-18.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 4:18:11 P.M.

VPN - PPTP - General Setup

Status : ☒ Active ☐ Inactive

PPTP Authentication :

PPTP Encryption :

User Authentication : ☒ Local ☐ RADIUS Server

Mutual Authentication

☒ Enable ☐ Disable

User Name :

Password :

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-18. PPTP general setup

Status	Sets the function to Active or Inactive .
PPTP Authentication	The authentication mode to be used. The default setting is CHAP .
PPTP Encryption	The encryption mode to be used. If PPTP authentication mode is set to CHAP or PAP, PPTP Encryption mode does not need to be set.
User Authentication	Sets user authentication to Local server or RADIUS server.
Mutual Authentication	
Status	Enables or Disables this function.
User Name	The user name.
Password	The password.

8.3.2.2 Group Setup

The Vigor3300 series provides up to four groups configurations in Figure 8-19.

The screenshot shows the web interface for the Vigor3300 series MultiService Security. The top navigation bar includes links for Quick Setup, System, Network, Advanced, Firewall, QoS, VPN, and VoIP. The main content area is titled "VPN - PPTP - Group Table" and contains a table with four columns: Group, Start IP, Subnet Mask, Accessed IP, and Subnet Mask. The table lists four groups (A, B, C, D) with their respective IP ranges and subnet masks. Below the table are "Apply" and "Cancel" buttons.

Group	Start IP	Subnet Mask	Accessed IP	Subnet Mask
A	192.168.1.224	/28	172.16.2.225	/24
B	192.168.1.225	/29	172.16.2.226	/25
C	192.168.1.226	/30	172.16.2.227	/26
D	192.168.1.227	/31	172.16.2.228	/27

Figure 8-19. PPTP group configuration

Start IP	The starting IP address. The default group value is 192.168.1.224/28.
Subnet Mask	The value of subnet mask for the Start IP.
Accessed IP	The accessed IP address.
Subnet Mask	The value of subnet mask for the Accessed IP.

8.3.2.3 Authentication Setup

Click the **Authentication** option to bring up the following web page (Figure 8-20). This page will display “User Name” and “Group” fields. Select an entry and click **Edit** to add a new entry in Figure 8-21.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP 4:31:18 P.M.

VPN - PPTP - Authentication

#	User Name	Group
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

1

Edit Delete Delete All

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-20. PPTP authentication configuration

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 4:32:07 P.M.

VPN - PPTP - Authentication - Edit

1

User Name : 3300

User Password :

Group : A

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-21. PPTP authentication entry

VPN and Remote Access Setup

User Name	The user name for this entry.
User Password	The password for this entry.
Group	The group for this entry.

Click **Apply** to apply these settings.

8.3.2.4 Status

Click the **Status** option to bring up the following web in Figure 8-22. This page displays some relevant information about PPTP connection. It will refresh automatically every 10 seconds.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 3:07:51 P.M.

VPN - PPTP - Status

#	Index	Remote IP	Assigned IP	User	Byte In	Byte Out	Up Time
1	1	61.31.162.252	192.168.1.224	3300	1280	74	11

Refresh Disconnect

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 8-22. PPTP status

CHAPTER 9

VoIP Setup

This chapter shows how to configure VoIP function.

This chapter is divided into the following sections.

- Section 9.1: Introduction
- Section 9.2: Protocol Setup
- Section 9.3: Port Settings Setup
- Section 9.4: Speed Dial Setup
- Section 9.5: Advanced Speed Dial Setup
- Section 9.6: Miscellaneous Setup
- Section 9.7: Tone Settings Setup
- Section 9.8: QoS Setup
- Section 9.9: NAT Traversal Setup
- Section 9.10: Incoming Call Barring Setup
- Section 9.11: Call History
- Section 9.12: Status

9.1 Introduction

Voice over Internet Protocol (VoIP) is a technology that allows you to make telephone calls using a broadband Internet connection instead of a regular (or analog) phone line. The Vigor3300 provides cost effective voice solution for SME customers in Figure 9-1.

VoIP Setup




Figure 9-1. Vigor3300 VoIP application scenario

VoIP Setup

Click the VoIP option to set up VoIP configuration in Figure 9-2.





Figure 9-2. The VoIP menu

9.2 Protocol Setup

Click the **Protocol** option to bring up the following web page in Figure 9-3. There are two protocols in VoIP: **SIP** and **MGCP**.



Vigor3300 series MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 5:01:03 P.M.

VoIP - Protocol

Select Protocol : ☒ SIP ☐ MGCP

SIP Configuration MGCP Configuration

Figure 9-3. Protocol configuration

Select Protocol	The protocol to be used. There are two options: SIP , and MGCP . The default setting is SIP .
------------------------	--

9.2.1 SIP Configuration

The Vigor 3300V supports three SIP server settings in Figure 9-4.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 4:53:11 P.M.

VoIP - Protocol

Select Protocol : ☒ SIP ☐ MGCP

SIP Configuration MGCP Configuration

SIP Local Port : 5060

#	Active	Outbound Proxy	Proxy Name	Proxy Address	Proxy Port	Registrar Addr	Registrar Port	Expires (sec)	Domain
1.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	a	0	5060	0	5060	300	0
2.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	b	0	5060	0	5060	300	0
3.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	c	0	5060	0	5060	300	0
Example			iptel	iptel.org		iptel.org			iptel.org

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-4. SIP configurations

SIP Local Port –The port number for SIP protocol. The default value is 5060.

SIP Proxy Setting	
Active ¹	Click this square box to activate this SIP proxy server setting.
Outbound Proxy	Enable this function to send SIP protocol packets to an SIP proxy server.

¹ If the “LAN/VPN” option is selected in the VoIP IP Address field, it is recommended to keep each SIP proxy entry inactive to keep connections of VoIP applications.

VoIP Setup

Proxy Name	The name of the SIP proxy server.
Proxy Address	The IP address of the SIP proxy server.
Proxy Port	The port number of the SIP proxy server.
Registrar Address	The IP address or domain name of the SIP registrar server.
Registrar Port	The port number of the SIP registrar server.
Expires	The timeout value for SIP protocols. The default value is 300.
Domain	The IP address or domain name of the SIP Domain/Realm.

Click **Apply** to apply these settings.

9.2.2 MGCP Configuration

Click **MGCP** to bring up the following web page in Figure 9-5.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall VPN VoIP

VoIP - Protocol

Select Protocol : ☐ SIP ☒ MGCP

SIP Configuration **MGCP Configuration**

MGCP Local Port : 2427

MGCP Call Agent Address : 192.168.100.100

MGCP Call Agent Port : 2727

EndPoint Name Style : ☒ aain#@[ip_addr] ☐ mac_addr#@[ip_addr] ☐ aain#@[mac_addr]

Wild-carded RSIP : ☒ Each endpoint sends its own RSIP ☐ Send only one wild RSIP

Apply Cancel

DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-5. MGCP configuration

VoIP Setup


MGCP Local Port	The UDP port number in MGCP local terminal.
MGCP Call Agent Address	The IP address of the Call Agent server in MGCP.
MGCP Call Agent Port	The UDP port number for the Call Agent server.
EndPoint Name Style	There are three options: <u>aaln/#@[ip_addr]</u> ex: aaln/1@[1.1.1.1] <u>mac_addr/#@[ip_addr]</u> ex: 000504030201/1@[1.1.1.1] <u>aaln/#@mac_addr</u> ex: aaln/1@000504030201
Wild-carded RSIP	There are two options: Each endpoint sends its own RSIP Send only one wild RSIP

9.3 Port Settings Setup

There are two parts to this feature. They are described in greater details as below.

9.3.1 Phone Number Configuration

Click **VoIP -> Port settings** to configure basic information for VoIP in Figure 9-6.











Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 5:07:33 P.M.

VoIP - Port Settings

#	Edit	Type	Active	Group	Username	Proxy	Codec
1		FXS	V	1	1001	a	G.729A-8kbps
2		FXS	V	1			
3		FXS	V	1			
4		FXS	V	1			
5		FXS	V	5	1005	a	G.729A-8kbps
6		FXS	V	6	1006		G.729A-8kbps
7		FXS	V	7	1007		G.729A-8kbps
8		FXS	V	8	1008		G.729A-8kbps

DrayTek Corp., © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-6. The port settings configuration

VoIP Setup

Click **Edit** to bring up the following web page in Figure 9-7.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 5:43:07 P.M.

VoIP - Port Settings - Port1 - Edit

Port 1 (FXS)

☐ Disable ☒ Enable

Username: 1001

Password: ••••

Display Name: 1001

Proxy Server: a

VoIP IP Address: WAN

Hotline

Hotline Number to Internet: 888123

Hotline Number to PBX / PSTN:

FXO

Manual Disconnection: Disconnect

Codec

Preferred Codec: G.729A -8kbps

Codec Rate: 20 (ms)

Codec VAD: ☒ Disable ☐ Enable

CAS

RX Gain: 0 (Range: -32 ~ 31)

TX Gain: 0 (Range: -32 ~ 31)

FAX

FAX Mode: T.38 Relay

FAX Bypass Codec: G.711U (PCMU) -64kbps

FAX Bypass Codec Rate: 20 (ms)

DTMF

DTMF Relay: ☐ Disable ☒ RFC2833 ☐ SIP INFO

Call Forwarding

☐ Disable

☐ Call forwarding all calls

☐ Call forwarding busy

☒ Call forwarding no answer after 3 rings (Range: 1~10)

SIP URL: www.iptel.com

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-7. Edit phone number configuration

VoIP Setup

Port 1 (FXS)	
Selective Box	Enable or Disable this port.
User Name	The user name (a number) for each phone line.
Password	The user password for each phone line.
Display Name	The user name to be displayed on another phone terminal.
Proxy Server	The SIP proxy server to be applied on this port.
VoIP IP Address	The interface is used to apply VoIP traffics. There are two options: WAN and LAN/VPN . If LAN/VPN is selected, VoIP can be applied through a VPN tunnel to create a high security voice phone.

Hotline	
Hotline Number to Internet	Pre-set this phone number to make the port dial out to Internet automatically.
Hotline Number to PBX / PSTN	Pre-set this phone number to make the port dial out to PBX/PSTN automatically.

FXO	
Manual Disconnection	Click “Disconnect” button to disconnect this phone line by manual.

Codec	
Preferred Codec	The Codec to be applied on this port. Vigor3300 supports five Codecs.
Codec Rate	The rate value to be applied on this port.
Codec VAD	Enable or Disable VAD (Voice Activity Detection).

VoIP Setup

CAS	
RX Gain	The gain value while receiving voice. The default value is 0. The range is from -32 to 31.
TX Gain	The gain value while transmitting voice. The default value is 0. The range is from -32 to 31.
FAX	
FAX Mode	<p>The FAX function mode. There are three options:</p> <p>Transparent: FAX will be transmitted via voice channel; no fax relay and no Codec change will be involved.</p> <p>T.38 Relay: Using T.38 Fax Relay. This is the default value.</p> <p>Bypass: Once FAX is detected, the Codec will automatically switch to a high bit rate type (G.711a/u or G.726) to make sure FAX can transmit successfully.</p> <p>If this option is selected, the Vigor3300 will apply these two following settings (FAX Bypass Codec and FAX Bypass Codec Rate).</p>
FAX Bypass Codec	Select one option to be applied if FAX mode is configured as Bypass mode.
FAX Bypass Codec Rate	Select one option to be applied if FAX mode is configured as Bypass mode.

VoIP Setup

DTMF	
DTMF Relay	The DTMF Relay function. There are three options to be supported as below: Disable RFC2833 SIP INFO
Call Forwarding	Click “Disable” to disable forwarding function. Click “Call forwarding all calls” to forward all callings. Click “Call forwarding busy” to forward callings when this line is busy. Click “Call forwarding no answer after (Range: 1~10) rings” to forward callings after ringing 1~10 times.
SIP URL	Assign a SIP URL site to be confirmed by call forwarding function.

Click **Apply** to apply these settings.

Note

- 1. The default internal phone numbers are “01”, “02”, “03”...”08” for each port. These numbers can be dialed for internal phone line usage.*
 - 2. If the FAX function needs to be used, it is advisable to configure the same FAX mode settings between the two VoIP routers.*
- The FAX mode option will be varied depends on which Codec has been selected (see table).*

<i>Codec</i>	<i>Allowed FAX Modes</i>
<i>G.711U</i> <i>G.711A</i> <i>G.726</i>	<i>Transparent, T.38, Bypass</i>
<i>G.729A</i> <i>G.723.1</i>	<i>T.38, Bypass</i>

9.3.2 Group Configuration

It is very important to provide a Group function for voice service within a company. Customers can simultaneously call the same phone number. When the Vigor3300 gets a phone call, which is configured in the first port of a group from Internet, it will ring all available ports belonging to this group to provide voice service at the same time. It is easier for the customer to remember just one phone number corresponding to the company. By enabling this function, the 4 or 8 port VoIP will use the first enabled port phone setting on the table as their phone number.

Up to 8 groups can be configured and assigned a specific phone line. Each phone line must be unique and cannot be overlapped in Figure 9-8².

² *Each group has a default leading port. If this group has more than one port, the settings for all ports have to follow the setting of the leading port.*

VoIP Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick SetupSystemNetworkAdvancedFirewallQoSVPNVoIP5:33:57 P.M.

VoIP - Port Settings

Phone NumberGroup

Group :
☐ Disable ☒ Enable

Group	Port							
	1	2	3	4	5	6	7	8
1	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
5	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
8	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>

Incomming Call Rings
☒ Rings all ports in the group ☐ Rings the first available port

Default GroupApplyCancel

DrayTek Corp., © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-8. The group configuration

9.4 Speed Dial Setup

This feature provides a simple way to dial a specific number. Up to 150 numbers can be stored in Vigor3300V.

Click **VoIP -> Speed Dial** to set up dialing entries in Figure 9-9.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 5:49:37 P.M.

VoIP - Speed Dial

#	Speed Dial Phone Number	Speed Dial Destination	Memo
1	1001	1001@iptel.org	Dial1
2	1002	1002@iptel.org	Dial2
3	1003	1003@iptel.org	Dial3
4	1004	1004@iptel.org	Dial4
5	1005	1005@iptel.org	Dial5

Example 101 101@iptel.org

1 2 3 4 5 6 7 8 9 10 >

Apply Cancel Clear This Page

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-9. The speed dial configuration

Speed Dial Phone Number	The phone number to be dialed.
Speed Dial Destination	The dialing destination address.
Memo	A description for each number.

Click **Apply** to apply these settings.

9.5 Advanced Speed Dial

Click **VoIP ->Advanced Speed Dial** to configure the setting as shown in Figure 9-10.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 5:56:31 P.M.

VoIP - Advanced Speed Dial

#	Prefix	Strip Length	Append	Destination	Memo
1	<input checked="" type="radio"/> 0		1		
2	<input type="radio"/>				
3	<input type="radio"/>				
4	<input type="radio"/>				
5	<input type="radio"/>				
6	<input type="radio"/>				
7	<input type="radio"/>				
8	<input type="radio"/>				
9	<input type="radio"/>				
10	<input type="radio"/>				

Edit Delete Delete All

DrayTek Corp., © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-10. The advanced speed dial configuration

VoIP Setup

Click **Edit** to configure one entry and the following web page as shown in Figure 9-11.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 6:12:37 P.M.

VoIP - Advanced Speed Dial - Edit

1	
Prefix :	<input type="text" value="03"/>
Strip Length:	<input type="text" value="0"/>
Append :	<input type="text" value="886"/>
Destination :	<input type="text" value="10.1.1.1"/>
Memo :	<input type="text" value="Memo1"/>

Apply Cancel

DrayTek Corp., © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-11. Advanced speed dial edit page

<i>Prefix</i>	Assign a prefix of phone number to be checked.
<i>Strip Length</i>	Assign the length of digit to be removed.
<i>Append</i>	Assign the number to be added before a phone number.
<i>Destination</i>	Assign a destination address to be sent.
<i>Memo</i>	A description for this entry.

9.6 Miscellaneous Setup

Miscellaneous Setup includes **RTP** and **T.38 Starting Port**, **T.38 Redundancy Number** and **VoIP ToS** settings. Click **VoIP -> Miscellaneous** to configure Miscellaneous Setup in Figure 9-12.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 3:28:28 P.M.

VoIP - Miscellaneous

RTP Starting Port:

T.38 Starting Port:

T.38 Redundancy number: (Range: 0~4)

VoIP ToS:

FXO auto disconnection if no packet is received in minutes. (Range: 1~60, 0: no auto disconnection)

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-12. Miscellaneous configuration

RTP Starting Port	The starting port number for RTP protocol packet. The default setting is 13456.
T.38 Starting Port	The starting port number for T.38 protocol packet. The default setting is 49170.
T.38 Redundancy Number	The redundancy number (how many payloads to attach to the tail of the packet) for T.38 protocol. The default value is 1.
VoIP ToS	The ToS value in VoIP protocol packet. The default setting is 0xa0.

Click **Apply** to apply these settings.

9.7 Tone Settings Setup

Click **VoIP->Tone Settings** to configure the **Tone Settings** in Figure 9-13.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 3:32:01 P.M.

VoIP - Tone Settings

Region: Caller ID Type:

Tone Classification	Low Frequency(Hz)	High Frequency(Hz)	TOn1(10msec)	TOff1(10msec)	TOn2(10msec)	TOff2(10msec)
Dial tone	<input type="text" value="350"/>	<input type="text" value="440"/>	<input type="text" value="500"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
Ringing tone	<input type="text" value="440"/>	<input type="text" value="480"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="200"/>	<input type="text" value="400"/>
Busy tone	<input type="text" value="480"/>	<input type="text" value="620"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="50"/>	<input type="text" value="50"/>
Congestion tone	<input type="text" value="480"/>	<input type="text" value="620"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="25"/>	<input type="text" value="25"/>

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-13. The tone setting configuration

Region	The country area for using VoIP feature. Select User Defined for proprietary settings.
Caller ID Type	If User Defined is selected in the Region field, users can select one of the supported values. If a country is selected, this field will display ID type value automatically.

There are four kinds of tones provided: **Dial tone**, **Ringing tone**, **Busy tone** and **Congestion tone**).

Dial tone – A tone means the phone line is ready to make a call.

Ringing tone – A tone means the call is ringing.

Busy tone – A tone means the phone line is busy.

Congestion tone – A tone means the network is busy.

VoIP Setup

Low Frequency (Hz)	The low frequency number in Hertz.
High Frequency (Hz)	The high frequency number in Hertz.
Ton1 (10msec)	The duration of the first ring.
Toff1 (10msec)	The silence duration after the first ring.
Ton2 (10msec)	The duration of the next continuous ring.
Toff2 (10msec)	The silence duration after the next continuous ring.

9.8 VoIP QoS³ Setup

Click **VoIP->QoS** to bring up the following web page as Figure 9-14.

Figure 9-14. VoIP QoS configuration

Status	Enable or Disable QoS function
---------------	---------------------------------------

Click **Apply** to apply these settings.

³ *This Quality of Service (QoS) function is only for the VoIP feature. When this function is enabled, the Vigor 3300 will set rate limitation for incoming and outgoing transmissions to ensure the best quality of service in VoIP.*

9.9 NAT Traversal Setup

NAT traversal is a challenge that all Service Providers looking to deliver public IP-based voice and multimedia services must solve. The goal is to provide secure connection to subscribers behind NAT (Network Address Translation) devices and Firewalls. Overcoming this traversal problem will lead to widespread deployment of profitable voice and multimedia over IP services to any subscriber with broadband connection.

The Vigor3300 series supports this feature to keep voice application behind any NAT routers as it is in Figure 9-15.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 6:25:09 P.M.

VoIP - NAT Traversal

NAT Traversal

☒ Disable
☐ Manually Input NAT IP Address
☐ Auto Discover NAT IP Address

NAT IP Address : 127.0.0.1

☐ Semi-auto, need to config NAT
☒ Full-auto, no need to config NAT

STUN Local Port : 3478

STUN Server Address : stun.fwdnet.net

STUN Server Port : 3478

Symmetric Media

☒ Disable symmetric RTP and T.38
☐ Enable symmetric RTP and T.38

NAT Status

NAT Type: N/A, Local IP Address: 172.16.2.225, WAN IP Address: 172.16.2.225

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-15. NAT traversal configuration

VoIP Setup

There are three parts supported as below.

<i>Disable</i>	Disable this function. The feature is used if 3300V has a public WAN IP address and not behind a NAT router.
<i>Manually Input NAT IP Address</i>	
NAT IP Address	The IP address to be used as the NAT IP address. The feature is used if 3300V is behind a NAT router, and the NAT router uses static WAN IP address. This value is the same as the WAN IP of the front NAT router.
<i>Auto Discovery NAT IP Address</i>	
Semi-auto	Click this function; User needs to configure NAT information.
Full-auto	Click this function; User does not configure NAT information.
STUN Local Port	The port number of the STUN server.
STUN Server Address	The IP address of the STUN server.
STUN Server Port	The server port number of the STUN server.
<i>Symmetric Media</i>	
Disable	RTP and T.38 are not symmetrical.
Enable	RTP and T.38 are symmetrical.

Note

“Auto Discovery NAT IP Address” option is used when the Vigor3300 is behind a NAT router, and the NAT router uses a dynamic WAN IP address such as a DHCP or PPPoE client. The Vigor3300 requires a STUN server for this option.

Note

The “STUN” (Simple Traversal of UDP through NATs) server is an implementation of the STUN protocol that enables STUN functionality in SIP-based systems. STUN is an application-layer protocol that can determine the public IP and nature of a NAT device that sits between the STUN client and STUN server.

9.10 Incoming Call Barring Setup

This feature is used to bar incoming VoIP calls from the Internet. Barring classes can be specified to allow or deny incoming calls. There are five barring classes on the device. The default setting is “Allow all incoming calls.”

9.10.1 Set

Click the **Set** option to bring up the following web page as Figure 9-16.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advance Firewall QoS VPN VoIP 8:08:02 P.M.

VoIP - Incoming Call Barring - Set

Barring Class
 Allow only calls from allow list

Match Method
 Name : ☒ Disable ☐ Enable Remind:
 IP/Domain : ☒ Disable ☐ Enable Remind:

Speed Dial Entries
 From: 1 To: 30

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 9-16. Set incoming call barring configuration

Barring Class	<p>There are five options as below.</p> <ul style="list-style-type: none"> ● Allow all incoming calls. ● Allow only calls from allow list. ● Allow only calls from speed dial entries ● Deny only calls from deny list. ● Deny all incoming calls.
----------------------	--

VoIP Setup

Match Method	
Name	Enable or Disable this function to take value of Speed Dial Phone Number to be checked.
IP/Domain	Enable or Disable this function to take the value of Speed Dial Destination to be checked.
Speed Dial Entries	The range to be checked. The default value is from 1 to 150.

9.10.2 Allow List⁴

Click the **Allow List** option to bring up the following web page as Figure 9-17.

The screenshot shows the Vigor3300 series MultiService Security web interface. The top navigation bar includes links for Quick Setup, System, Network, Advance, Firewall, QoS, VPN, and VoIP. The VoIP section is active, and the time is 8:41:05 P.M. The main content area is titled "VoIP - Incoming Call Barring - Allow List". It features a table with columns for #, Name, and IP/Domain. The table contains five rows, with the first two rows filled with "Tom" and "192.168.1.66", and "Jim" and "iptel.org". Below the table, there is an "Example" row with "Free Text" and "192.168.1.1/iptel.org". At the bottom right, there are "Apply" and "Cancel" buttons. A footer at the bottom of the page reads: "DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution."

#	Name	IP/Domain
1	Tom	192.168.1.66
2	Jim	iptel.org
3		
4		
5		
Example	Free Text	192.168.1.1/iptel.org

Figure 9-17. Allow list configuration

⁴ The Vigor3300 series supports up to 30 entries in the AllowList table.

VoIP Setup

Name	The name or number in the allow list.
IP/Domain	The IP address or domain name to be allowed. If the peer is registered in SIP proxy server, use the domain name of the SIP proxy server. Otherwise, use the static IP address or DDNS domain name.

9.10.3 Deny List⁵

Click **Deny List** to bring up the following web page as Figure 9-18.

Figure 9-18. Deny list configuration

⁵ Note

Vigor3300 series of router support up to 30 entries in deny list table.

Name	The name or number in the deny list.
IP/Domain	The IP address or domain name to be denied. If the peer is registered in SIP proxy server, use the domain name of the SIP proxy server. Otherwise, use the static IP address or DDNS domain name.

9.11 Call History

Click **VoIP->Call History** to bring up the connection history status page in Figure 9-19. Click “**Refresh**” to get the latest status information for these VoIP phones. The page refreshes automatically every 10 seconds.




Figure 9-19. VoIP call history log

VoIP Setup

<i>Port Number</i>	The port number of VoIP.
<i>Call Type</i>	The dialing direction for this call (Incoming/Outgoing).
<i>Caller Number</i>	The phone number of the caller.
<i>Callee Number</i>	The phone number of the receiver.
<i>Start Time</i>	The starting time of the call.
<i>End Time</i>	The ending time of the call.
<i>Duration</i>	The duration of the call.
<i>Release Reason</i>	The reason for the call termination.
<i>Remote RTP Address</i>	The IP address of remote voice site.
<i>Remote RTP Port</i>	The used port number of remote voice site.
<i>RTP Statistic</i>	The statistic of RTP.
<i>Codec Type</i>	The Codec mode used for this phone calling.
<i>Packet Period</i>	The period of time for sampling on voice signal.
<i>VAD</i>	The status of VAD.
<i>DTMF Relay</i>	The status of DTMF.

9.12 Status

Click **Status** to bring up the connection status page as Figure 9-20.




Figure 9-20. VoIP status

Register Status	The status of registering in proxy server.
Call Status	The calling status.
Call Type	The dialing direction for this call (Incoming/Outgoing).
Caller Number	The phone number of the caller.
Callee Number	The phone number of the receiver.
Start Time	The starting time of the call.
Remote RTP Address	The IP address of the remote voice site.
Remote RTP Port	The used port number of the remote voice site.
Codec Type	The Codec mode used for this phone call.
Packet Period	The period of time for sampling on voice signal.
VAD	The status of VAD.
DTMF Relay	The status of DTMF.

VoIP Setup

Click “**Refresh**” to get new status information for these VoIP phones. The page refreshes automatically every 10 seconds.

CHAPTER 10

Quality of Service Setup

This chapter shows how to configure the capabilities of the QoS facility and uses the following setup link on the Main Menu to configure the QoS control function.

This chapter is divided into the following sections.

- Section 10.1: Introduction
- Section 10.2: Incoming/outgoing Class Setup
- Section 10.3: Incoming/outgoing Class Filter Setup

10.1 Introduction

The QoS (Quality of Service) guaranteed technology in the Vigor 3300 series allows the network administrator to monitor, analyze, and allocate bandwidth for various types of network traffic in real-time and/or for business-critical traffic. Thus, timing-sensitive applications will not be impacted by web surfing traffic or other non-critical applications, such as file transfer. Without QoS-guaranteed control, there would be virtually no way to prioritize users/services or guarantee allocation of finite bandwidth resources to network or servers for supporting timing-sensitive and mission-critical network applications, such as VoIP (Voice over IP) and online gaming applications. Differentiated quality of service is therefore one of the most important issues over the Internet infrastructure. In the Vigor

Quality of Service Setup

3300 series DSCP (Differentiated Service Code Point) support is also taken into consideration in the design of the QoS-guaranteed control module.

In the **QoS** group, Figure 10-1 illustrates the functions of **QoS** option.

The QoS function handles incoming and outgoing classes independently. Users can configure incoming or outgoing separately without any impact on the other.

Click the **QoS** option to bring up the QoS Setup menu as Figure 10-1




Figure 10-1. The QoS menu

10.2 Incoming/Outgoing Class Setup

This section describes how to configure incoming/outgoing classes.

Click **Incoming Class Setup** to see the following setup page as Figure10-2.

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 9:55:30 A.M.

QoS - Incoming Class Setup

☐ Disable ☒ Enable

Index	Class Name	Bandwidth
1.	ClassA	30 %
2.	ClassB	20 %
3.	ClassC	10 %
4.		%
5.		%
6.		%
7.		%
8.	others	%

Apply Cancel Clear All

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 10-2 The QoS class configuration

Status	Enable or Disable this function.
Index	The number for each queue.
Class Name	The name for each queue.
Bandwidth	The usage percentage for each queue.

Quality of Service Setup

There are eight queues that can be configured. The total sum of bandwidth has to be 100 percent for all configured queues. Any leftover bandwidth is assigned to eight queues to meet 100 percent totally.

Click **Apply** to apply these settings.

10.3 Incoming/Outgoing Class Filter Setup

This section describes how to configure each queue as below.

Click **Incoming Class Filter** to see the following setup page as Figure10-3.

Figure 10-3. Class Filter configuration

Click **Edit** to bring up the following page and edit filter conditions to be applied on the specific queue in Figure 10-4.

Quality of Service Setup

Vigor3300 series
MultiService Security

VIGOROUS BROADBAND ACCESS

Quick Setup System Network Advanced Firewall QoS VPN VoIP 6:54:02 P.M.

QoS - Incoming Class Filter - Edit

Source IP: 10.1.1.1 /24

Destination IP: 10.1.2.1 /24

Service Type Status: ☒ Basic ☐ Advanced ☐ None

Service Type: AUTH(TCP: 113)

Protocol: TCP

Port:

DiffServ CodePoint Status: ☒ Basic ☐ Advanced ☐ None

DiffServ CodePoint Type: BE

DiffServ CodePoint: 0x (Hex)

Class: undefined

Apply Cancel

DrayTek Corp. © 1997 - 2005 All rights reserved. DrayTek provides enterprise network solution.

Figure 10-4. Edit Incoming Class Filter

Source IP	The source IP address with subnet mask value to be applied.
Destination IP	The destination IP address with subnet mask value to be applied.
Service Type Status	There are three options: Basic – The Service Type field can be configured. Advanced – The Protocol and Port fields can be configured. None – No fields need to be configured.
Service Type	The service type to be used. There are thirty-five service types supported.
Protocol	There are three options: TCP , UDP , and TCP/UDP .
Port	The port number to be applied.

Quality of Service Setup

DiffServ CodePoint Status	<p>There are three options:</p> <p>Basic – The DiffServ CodePoint Type field can be configured.</p> <p>Advanced – The DiffServ CodePoint field can be configured.</p> <p>None – No fields need to be configured.</p>
DiffServ CodePoint Type	There are twenty-one types supported (Figure 10-5).
DiffServ CodePoint	The number (by hex mode) to be applied.
Class	The filtering conditions to be applied.

Figure 10-5. DiffServ CodePoint type list

Click **Apply** to apply these settings.


APPENDIX A

PC Web Browser Setup

The chapter describes the setup of PC to configure Vigor 3300. The setup items are including PC IP setting to communicate with Vigor 3300, Microsoft Web Browser version.


Part1-PCs/LAN communicating with Vigor 3300

1. Your PC should be connected to the router via an Ethernet (RJ45) cable. Then, the appropriate Ethernet switch LED (1/2/3/4) will light up (green = 100Mbps, off = 10Mbps). The Vigor3300's Ethernet ports are auto-sensing to speed and cable configuration. It can automatically adjust crossover/straight or uplink/normal connections.
2. Every device on your network must have a unique IP address. The router's DHCP server facility will automatically allocate these to your client PCs, assuming that they are set to obtain their details automatically. The default IP address of Vigor 3300 is 192.168.1.1 and all local PCs must have an IP address within the same 'subnet', e.g. IP address should be 192.168.1.10 or 192.168.1.254 for local PCs.
3. Check that the PC is actually getting the IP details from Vigor 3300. You can check this from the winipcfg utility. To run this, press the Windows Start button, select 'Run', type **winipcfg** and press OK.



In the above example, the PC has been given an IP address of 192.168.1.2 and has been told that the default gateway (router) is at 192.168.1.1. Ensure that your network card is selected in the top pulldown box (not 'PPP Adaptor'). If you click 'Release', the details should be cleared 'Renew' should get them back.


If you do not have the winipcfg utility, you can try **ipconfig.exe** from the MS-DOS command prompt.




Winipcfg is not supplied as standard with Windows 2000.

4. In **Windows XP**, you can check your PC's current IP address by opening Network Connections; if you select the LAN connection, the settings will appear on the left of the screen—like the example below. Here we can see that the Network connection is


enabled and that the PC has obtained an IP address of 192.168.1.10.




You can obtain the same information by right clicking on the Network Connection's icon in the system tray and selecting 'Status'.




5. If your PC is not getting an IP address (as described in previous sections), you need to check that your PC's TCP/IP settings are correct. As mentioned earlier, we recommend that you make use of the router's DHCP facility, which is enabled by default. From Windows98/Me Control Panel/Network, check your TCP/IP Properties are like this:






6. For **Windows XP**, the LAN/Network card setup is very similar to Windows98/Me, but the screens look a little different. Once your network card (Ethernet 10/100BaseT) is installed, it may be automatically set up correctly by default. You can check the settings from your PC's 'Network Connections' menu.


PC Web Browser Setup



Select the TCP/IP protocol as shown below and click on 'properties' and then check that.


Obtain IP address & DNS Automatically are both selected:





7. For **Apple MacOS**, to select and enable the DHCP client facility on your computer, the TCP/IP control panel should be set like this for MacOS 8/9 and X respectively.


PC Web Browser Setup



Once IP addresses are assigned by Vigor 3300, then they will appear on the above screen.

8. If you are **not** using DHCP (i.e. 'Obtain IP Address Automatically' as shown above) then you must manually give your PCs an IP address, This address must be within the same subnet as the router's own LAN IP address. This means that if the router is 192.168.1.1, then the other PCs must be numbered 192.168.1.nnn where 'nnn' is a number from 2 to 254. Additionally, each PC must have the 'Default Gateway' and "DNS Server Address" set to the router's IP address (192.168.1.1 unless you changed it.) None of this is necessary if you are using DHCP, hence it's recommended to rely on DHCP whenever possible.

9. To confirm the connectivity between your PC and the router, you can use the Windows 'ping' utility. This sends a small packet to the router, which the router sends back, to confirm the connectivity. From an MS-DOS prompt, enter 'ping 192.168.1.1' and you should get replies with a time in milliseconds (e.g. 12ms).




```
Microsoft(R) Windows 98
(C) Copyright Microsoft Corp 1981-1999.
C:\>ping 192.168.0.254
Pinging 192.168.1.1 with 32 bytes of data:
Reply from 192.168.1.1: bytes=32 time=3ms
Reply from 192.168.1.1: bytes=32 time=1ms
Reply from 192.168.1.1: bytes=32 time=1ms
Reply from 192.168.1.1: bytes=32 time=1ms
Ping statistics for 192.168.0.254:
    Packets: Sent = 4, Received = 4, Lost = 0
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 3ms, Average = 1ms
C:\>
```

Part2-Setup and Check your Web Browser Version

10. The above checks will confirm that your PC and network are connected to the Vigor 3300 correctly, so you should be able to access the Vigor 3300's Web Configuration interface. This is the main method for setting up, controlling and monitoring the router. Load your updated standard web browser (e.g. IE 6.0 or Netscape 7.1 is preferred.). You can go to www.microsoft.com and then on **resources** field to choose **downloads** item. **Search for a Download on Product/ Technology** field to find **Internet Explore** software. You can choose newest update Internet Explore version e.g. Internet Explore 6.


PC Web Browser Setup

11. Press bar and simply enter `http://192.168.1.1` (that is the default IP of Vigor 3300). Enter login by user name and password. The factory default for username is “Draytek”, and password is “1234”, then click **OK**. The login message is shown as below.



The image shows a Windows-style dialog box titled "Enter Network Password". It contains a key icon and the text "Please type your user name and password." Below this, there are fields for "Site:" (192.168.1.1), "Realm:" (.), "User Name:" (draytek), and "Password:" (masked with asterisks). There is a checkbox labeled "Save this password in your password list" which is unchecked. At the bottom right are "OK" and "Cancel" buttons.

Then, the main menu should appear as shown below.



The image shows the main menu of the Vigor3300 series MultiService Security web interface. The header features the "Vigor3300 series MultiService Security" logo and the tagline "VIGOROUS BROADBAND ACCESS". Below the header is a navigation bar with tabs: "Quick Setup", "System", "Network", "Advance", "Firewall", "VPN", and "VoIP". The "System" tab is selected, showing the "System - Status" page. This page has three sub-tabs: "Basic Status", "LAN Status", and "WAN Status". The "Basic Status" tab is active, displaying the following information:

Basic Status	
Model :	Vigor3300V
Firmware Version :	2.5.3
Hardware Version :	0
Build Date&Time :	Thu Aug 12 16:50:22 CST 2004
System Uptime :	723.09
CPU Usage :	7.1194%
Memory Usage :	31.9441%

At the bottom of the page, there is a footer line: "DrayTek Corp. © 1997 - 2004 All rights reserved. DrayTek provides enterprise network solution."